



**Technical Information** 

# PLUS+1<sup>®</sup> Mobile Machine Displays DM1x00 Series





# **Revision history**

# Table of revisions

Date	Changed	Rev
October 2021	Minor typographical edits and statistical correction	0204
August 2021	Updated Machine wiring guidelings and LCD features	0203
December 2020	Corrected Pin Assignment tables	0202
December 2019	Under Pin assignments C1-C9, corrected tables for C5,C6, C7, and C8; and under DM1x00 Series Displays description, Dual core 1.2 GHz i.MX6 replaced with Dual core 800 MHz i.MX6	0201
October 2019	First edition	0101



# Contents

DM1x00 literature re	of a vome as	
DM 1X00 literature re	Technical Information (TI)	,
	Data Sheet (DS)	
	PLUS+1° GUIDE User Manual	
	Latest version of technical literature	
	Latest version of technical interactife	
User liability and safe		
	OEM responsibility	
	Safety statements	
	Display operation guidelines	
	Machine wiring guidelines	
	Machine welding guidelines	
Overview		
Overview	DM1v00 Sories Displays description	•
	DM1x00 Series Displays description Features	
	PLUS+1° GUIDE	
	LCD features	
<b>Ordering information</b>	n	
	Model variants	10
	Model code	10
	Model code key	10
	Related products	1 <sup>1</sup>
	L vy	
Input/output types a		4.
	Specifications	
	Input types	
	Digital/analog	
	Multifunction inputs	
	CAN shield and analog input	
	Digital output	
	CAN communication	
	USB communication	
	RS232 communication	
	Sensor output	17
	Video power	
	Officially validated digital camera formats	
	Officially validated analog camera formats	
	Ethernet	
	Audio outputs	
	Wifi / Bluetooth	19
Product ratings		
1 Todact Tatings	DM1x00 environmental testing criteria	20
	Supply voltage/maximum current ratings	
	Ingress Protection (IP) rating	
	mgress rrocector (ii ) ruting	
Installation		
	DM1x00 Series Displays dimensions	22
	Button options	
	Pin assignments C1—C9	
	Standard Mount	
	Mounting panels cutouts	26
	RAM mount	26
	Fastening	26
	Visibility and viewing radius	27
	Display faulty application recovery	27
	Cleaning	



#### DM1x00 literature references

#### Reference literature

Literature title	Literature type	Literature number
DM1x00 Series PLUS+1° Mobile Machine Displays	Technical Information	BC313277849405
DM1x00 Series PLUS+1° Mobile Machine Displays	Data Sheet	Al304864913574
PLUS+1° GUIDE Software	User Manual	AQ152886483724

#### **Technical Information (TI)**

A TI is comprehensive information for engineering and service personnel to reference.

#### Data Sheet (DS)

A DS is summarized information and parameters that are unique to a specific model.

#### PLUS+1° GUIDE User Manual

The Operation Manual (OM) details information regarding the PLUS+1° GUIDE tool used in building PLUS +1° applications. This OM covers the following broad topics:

- How to use the PLUS+1° GUIDE graphical application development tool to create machine applications
- How to configure module input and output parameters
- How to download PLUS+1® GUIDE applications to target PLUS+1® hardware modules
- How to upload and download tuning parameters
- How to use the PLUS+1° Service Tool

#### Latest version of technical literature

Comprehensive technical literature is online at www.danfoss.com



#### User liability and safety statements

#### **OEM responsibility**

The OEM of a machine or vehicle in which Danfoss products are installed has the full responsibility for all consequences that might occur. Danfoss has no responsibility for any consequences, direct or indirect, caused by failures or malfunctions.

- Danfoss has no responsibility for any accidents caused by incorrectly mounted or maintained equipment.
- Danfoss does not assume any responsibility for Danfoss products being incorrectly applied or the system being programmed in a manner that jeopardizes safety.
- All safety critical systems shall include an emergency stop to switch off the main supply voltage for the outputs of the electronic control system. All safety critical components shall be installed in such a way that the main supply voltage can be switched off at any time. The emergency stop must be easily accessible to the operator.

#### Safety statements



#### Warning

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. Improperly protected power input lines against over current conditions may cause damage to the hardware. Properly protect all power input lines against over-current conditions. To protect against unintended movement, secure the machine.



#### Warning

At high ambient temperatures the metal housing can become hotter than 70°C. Please use caution when touching the metal housing of the display






#### Caution

Unused pins on mating connectors may cause intermittent product performance or premature failure. Be sure to plug all pins on mating connectors.

#### Display operation guidelines

- Disconnect your machine's battery power before connecting power and signal cables to the display.
- Before doing any electrical welding on your machine, disconnect all power and signal cables connected to the display.
- Do not exceed the display power supply voltage ratings. Using higher voltages may damage the display and can create a fire or electrical shock hazard.
- Do not use or store the display where flammable gases or chemicals are present. Using or storing the display where flammable gases or chemicals are present may cause an explosion.
- Software configures the keypad buttons on the display. Do not use these buttons to implement critical safety features. Use separate mechanical switches to implement critical safety features such as emergency stops.
- Design systems that use the display so that a communication error or failure between the display and other units cannot cause a malfunction that might injure people or damage material.
- The protective glass over the display screen will break if hit with a hard or heavy object. Install the display to reduce the possibility of it being hit by hard or heavy objects.
- Storing or operating a display in an environment that exceeds the display specified temperature or humidity rating may damage the display.

© Danfoss | October 2021





## User liability and safety statements

- Always clean the display with a soft, damp cloth. Use a mild dishwashing detergent as needed. To avoid scratching and discoloring the display, do not use abrasive pads, scouring powders, or solvents such as alcohol, benzene, or paint thinner.
- Keep ambient light sensor area clean and uncovered for best operation.
- Danfoss graphical displays are not user serviceable. Return the display to the factory in case of failure.



#### User liability and safety statements

#### Machine wiring guidelines

- Protect wires from mechanical abuse, run wires in flexible metal or plastic conduits.
- Use 85° C (185° F) wire with abrasion resistant insulation and 105° C (221° F) wire should be considered near hot surfaces.
- Use a wire size that is appropriate for the module connector.
- Separate high current wires such as solenoids, lights, alternators or fuel pumps from sensor and other noise-sensitive input wires.
- Run wires along the inside of, or close to, metal machine surfaces where possible, this simulates a shield which will minimize the effects of EMI/RFI radiation.
- Do not run wires near sharp metal corners, consider running wires through a grommet when rounding a corner.
- Do not run wires near hot machine members.
- Provide strain relief for all wires.
- Avoid running wires near moving or vibrating components.
- Avoid long, unsupported wire spans.
- Ground electronic modules to a dedicated conductor of sufficient size that is connected to the battery (-).
- Power the sensors and valve drive circuits by their dedicated wired power sources and ground returns.
- Twist sensor lines about one turn every 10 cm (4 in).
- Use wire harness anchors that will allow wires to float with respect to the machine rather than rigid anchors.

#### Machine welding guidelines



#### Warning

High voltage from power and signal cables may cause fire or electrical shock, and cause an explosion if flammable gasses or chemicals are present.

Disconnect all power and signal cables connected to the electronic component before performing any electrical welding on a machine.

The following is recommended when welding on a machine equipped with electronic components:

- Turn the engine off.
- Remove electronic components from the machine before any arc welding.
- Disconnect the negative battery cable from the battery.
- Do not use electrical components to ground the welder.
- Clamp the ground cable for the welder to the component that will be welded as close as possible to the weld.



#### Overview

#### DM1x00 Series Displays description

The Danfoss DM1x00 display series bring modern appearance and performance to mobile machine markets with two display platforms, expanding the PLUS+1° family.

The DM1x00 series was developed for best operator viewability with its high brightness, optical bonding, anti-glare, anti-reflection, oleophobic coating and wide viewing angles. It is equipped with an outstanding dual core 800 MHz i.MX6 processor and 4GB flash memory delivering high performance. Ruggedized for mobile machine markets, it is built to withstand harsh operating environments with its IP66 and IP67 rating and the water-resistant screen allowing for multi-touch while wearing gloves.

The integrated file viewer and media player provides view of documents and media files on the run using the audio line out to connect to the vehicle speaker system.

To meet specific needs, the DM1x00 includes two different screen sizes (10.1" and 12.1") with optional multi-touch and two button pad configurations with programmable back-lights and tactile feedback.

WiFi and Bluetooth® provide wireless channels for servicing the machine remotely.

#### **Features**

- 4 CAN ports
- RS232 and USB 2.0 high-speed
- Ethernet
- Bluetooth® and WiFi, GNSS (optional)
- 4 Camera inputs (Up to 2 displayed at one time)
- · Audio line out
- Sensor supply out
- Optional keypad with either 8 buttons on each side (16 total) or 8 buttons plus navigation panel (16 total)
- Backlit buttons
- Touch screen (optional)
- Optical signal (2 RGB LEDs)
- Integrated ambient light sensor for automatically adjusting brightness to lighting conditions
- Ignition input
- Wake up over input
- Dual core 800 MHz i.MX6
  - 4 GB Flash memory
- Media player and File viewer (PDF, JPG, MP3, MP4)
- PLUS+1® GUIDE programmable
- Real Time Clock (RTC)
- Rugged IP66 and IP67 rating
- 2 Integrated DEUTSCH connectors
- Fast Start-up Time (less than 5 seconds)
- RAM® or Bracket (optional) mount (portrait or landscape)
- Integrated accelerometer for auto-adjusting between screen orientations
- 32 MB App Log

#### PLUS+1° GUIDE

PLUS+1° GUIDE (Graphical User Integrated Development Environment) is a complete toolbox that generates downloadable applications for all programmable PLUS+1° Compliant products.

A screen editor allows easy development of applications by programmers without formal software development training. The expertise from a software engineer is not needed to find your way around in PLUS+1° GUIDE.



#### Overview



## Caution

Unwanted system failure may occur. Refer to PLUS+1\* GUIDE Software User Manual, AQ152886483724 for best programming practices. https://www.danfoss.com/en/products/software/dps/plus1-software/plus1-guide/#tab-overview

#### **LCD features**

#### DM1000 LCD 10.1" screen

Description	Value.	Unit	Notes
Screen Size	10.1	Inch	
Resolution	1280 x 800	Pixels	
Brightness	900	cd/m2	Value includes cover glass
Contrast Ratio	500:1		
Viewing Angle	± 85	Degree	vertical and horizontal
Color Depth	24	Bits	8 bits per color

#### DM1200 LCD 12.1" screen

Description.	Value.	Unit.	Notes.
Screen Size	12.1	Inch	
Resolution	1280 x 800	Pixels	
Brightness	900	cd/m2	Value includes cover glass
Contrast Ratio	500:1		
Viewing Angle	± 85	Degree	vertical and horizontal
Color Depth	24	Bits	8 bits per color



# **Ordering information**

## **Model variants**

Part number	Order code	Description
11223953	DM1000-0-0-0	10.1", Non-Touch, No Buttons
11223954	DM1000-0-1-0-0	10.1", Non-Touch, No Buttons, WIFI/BT/GNSS
11223955	DM1000T-0-0-0	10.1", Touch, No Buttons
11223957	DM1000T-0-1-0-0	10.1", Touch, No Buttons, WIFI/BT/GNSS
11223958	DM1000-0-0-1-0	10.1", Non-Touch, 2x8 Buttons
11223956	DM1000-0-0-2-0	10.1", Non-Touch, 1x8 + Navigation Buttons
11223959	DM1000-0-1-1-0	10.1", Non-Touch, 2x8 Buttons, WIFI/BT/GNSS
11223960	DM1000-0-1-2-0	10.1", Non-Touch, 1x8 + Navigation Buttons, WIFI/BT/GNSS
11223961	DM1000T-0-0-1-0	10.1", Touch, 2x8 Buttons
11223965	DM1000T-0-0-2-0	10.1", Touch, 1x8 + Navigation Buttons
11223962	DM1000T-0-1-1-0	10.1", Touch, 2x8 Buttons, WIFI/BT/GNSS
11223966	DM1000T-0-1-2-0	10.1", Touch, 1x8 + Navigation Buttons, WIFI/BT/GNSS
11223963	DM1200T-0-0-0	12.1", Touch, No Buttons
11223964	DM1200T-0-1-0-0	12.1", Touch, No Buttons, WIFI/BT/GNSS

Mounting kits are not included. Please see Related Product section for ordering info.

## **Model code**

A	В	С	D	E
DM1x00				

## Model code key

A—Model name	Description
DM1000	10.1" Non-Touch
DM1000T	10.1" Touch
DM1200T	12.1" Touch

B—Not configured	Description
0	NC

C—WIFI/BT/GNSS	Description
0	Without WIFI/BT/GNSS
1	With WIFI/BT/GNSS

D—Buttons	Description
0	No Buttons
1	2x8 Buttons
2	1x8 + Navigation Buttons

E—Not configured	Description
0	NC

10 | © Danfoss | October 2021



# **Ordering information**

# **Related products**

## Connector kit

10100944	DEUTSCH 12-pin Connector Kit (DTM06-12SA)
----------	---

## Cable kits

11231512	Cable, M12 4-Pin to USB Device A code			
11130713	Cable, M12 8-Pin to Lead Wires A code			
11130712	Cable, M12 5-Pin to Lead Wires A code			

# Panel mounting kits

11224242	Panel mounting kit for 10" Display unit with no buttons			
11224243	Panel mounting kit for 10" Display unit with buttons			
11224244	Panel mounting kit for 12" Display unit			

## Software

11179523	PLUS+1° GUIDE Professional Software (includes 1 year of
(Annual renewal with 11179524 to keep the software	software updates, a single user license, Service and
updates)	Diagnostic Tool and Screen Editor)

#### Connection tools

10100744	DEUTSCH Extraction tool size 20 red
10100745	DEUTSCH solid contacts terminal crimp tool



## **Specifications**

## Characteristics/certifications

Processor	800 MHz i.MX6
RAM	512 MB
FRAM	32 kB
Supply voltage	9 to 36 V <sub>DC</sub>
Connector	DEUTSCH DTM06-12SA and DTM06-12SB
Size	10.1" and 12.1"
Aspect ratio	16:10 wide view
Resolution	1280x800, IPS
Brightness	900 cd/m <sup>2</sup>
Contrast ratio	500:1
Viewing angle	±85° vertical and horizontal
Color depth	24 bit
IP rating	IP66 and IP67 front and back
Operating temperature	-30°C to +70°C [-22°F to +158°F]
Storage temperature	-40°C to +85°C [-40°F to +185°F]
Weight	DM1000: 2.106 kg [4 lb 10 oz] DM1000 (w/ buttons): 2.528 kg [5 lb 9 oz] DM1200: 2.722 kg [6 lb]
Vibration/Shock	IEC 60068-2-64 (3.17g) /2-27 (50g)
EMI/RFI rating	ISO 13766
Humidity	IEC 60068-2-78, 60068-2-30
Transients	ISO 7637/1, 2, 3

	DM1000	DM1200
FCC	Certified	Certified
CE/RED	Certified	
UKCA	Certified	
EAC	Certified	
Giteki	Certified	
RCM	Pending	
E1-Mark	Pending	

#### **Input types**

Each PLUS+1° Module input pin supports one of the above functional types. For pins with multiple functions, input configurations are user programmable using PLUS+1° GUIDE templates.

When using inputs in digital mode, it is advised to use the software selectable pull-up or pull-down resistors.



# Digital/analog

# Middle range

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	V	_	_	0.03	_
Minimum discernible voltage	V	5.69	5.78	5.88	_
Resolution	mV	_	1.4	_	_
Worst case offset and gain error	V	_	_	±0.14	V <sub>Measure</sub> = 5.78 V
Non-linearity	mV	_	_	±8.5	_
Input impedance	kΩ	232	233	234	No pull up or pull down
Input impedance (5V/GND)	kΩ	13.9	14.1	14.3	Pull up or pull down
Input impedance (2.5V)	kΩ	7.1	7.3	7.4	Pull up and pull down

# High range

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	V	_	_	0.16	_
Maximum discernible voltage	V	37.9	38.8	39.7	_
Resolution	mV	_	9.5	_	_
Worst case offset and gain error	V	_	_	0.95	V <sub>Measure</sub> = 38.8 V
Non-linearity	mV	_	_	±56.8	_
Input impedance	kΩ	109.1	109.3	109.5	No pull up or pull down (Vin < 5.7 V)
Input impedance (5V/GND)	kΩ	13.0	13.2	13.4	Pull up or pull down (Vin < 5.7 V)
Pull up and pull down input impedance (2.5V)	kΩ	6.9	7.0	7.1	Pull up and pull down (Vin < 5.7 V)

# **Multifunction inputs**

## Low range analog

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	mV	_	_	13	_
Maximum discernible voltage	mV	379	404	430	_
Resolution	mV	_	0.1	_	_
Worst case offset and gain error	mV	_	_	±0.6	V <sub>Measure</sub> = 404 mV
Non-linearity	mV	_	_	±26	_
Input impedance	kΩ	232	233	234	No pull up or pull down
Input impedance (5V/GND)	kΩ	13.9	14.1	14.3	Pull up or pull down
Input impedance (2.5V)	kΩ	7.1	7.3	7.4	Pull up and pull down



## Middle range analog

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	V	_	_	0.03	_
Maximum discernible voltage	V	5.69	5.78	5.88	_
Resolution	mV	_	1.4	_	_
Worst case offset and gain error	V	_	_	±0.14	V <sub>Measure</sub> = 5.78 V
Non-linearity	mV	_	_	±8.5	_
Input impedance	kΩ	232	233	234	No pull up or pull down
Input impedance (5V/GND)	kΩ	13.9	14.1	14.3	Pull up or pull down
Input impedance (2.5V)	kΩ	7.1	7.3	7.4	Pull up and pull down

# High range analog

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	V	_	_	0.16	_
Maximum discernible voltage	V	37.9	38.8	39.7	_
Resolution	mV	_	9.5	_	_
Worst case offset and gain error	V	_	_	±0.95	V <sub>Measure</sub> = 38.8 V
Non-linearity	mV	_	_	±56.8	_
Input impedance	kΩ	109.1	109.3	109.5	No pull up or pull down (Vin < 5.7 V)
Input impedance (5V/GND)	kΩ	13.0	13.2	13.4	Pull up or pull down (Vin < 5.7 V)
Input impedance (2.5V)	kΩ	6.9	7.0	7.1	Pull up and pull down (Vin < 5.7 V)

# Low range frequency (PPU)

Description	Unit	Minimum	Typical	Maximum	Comment
Range	Hz	0	_	10000	In steps of 1 Hz
Rising voltage threshold	mV	_	_	314	
Falling voltage threshold	mV	55	_	_	
Input impedance	kΩ	232	233	234	No pull up or pull down
Input impedance (5V/GND)	kΩ	13.9	14.1	14.3	Pull up or pull down
Input impedance (2.5V)	kΩ	7.1	7.3	7.4	Pull up and pull down

# Middle range frequency (PPU)

Description	Unit	Minimum	Typical	Maximum	Comment
Range	Hz	0	_	10000	In steps of 1 Hz
Range (phase and quad)	Hz	0	_	5000	In steps of 1 Hz
Rising voltage threshold	V	_	_	4.25	Voltage required for frequency input
Falling voltage threshold	V	0.97	_	_	Voltage required for frequency input
Input impedance	kΩ	232	233	234	No pull up or pull down



# Middle range frequency (PPU) (continued)

Description	Unit	Minimum	Typical	Maximum	Comment
Input impedance (5V/GND)	kΩ	13.9	14.1	14.3	Pull up or pull down
Input impedance (2.5V)	kΩ	7.1	7.3	7.4	Pull up and pull down

## Resistance input

Description	Unit	Minimum	Typical	Maximum	Comment
Range	Ω	6	_	10000	In steps of 1 Ω
Measurement error	%	_	_	7.1	@100Ω
		_	_	2.1	@1kΩ
		_	_	5.4	@10kΩ
Input impedance	Ω	1320	1320	1330	No pull up or pull down

# Current input (4-20 mA)

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible current	mA	_	_	0.12	_
Maximum discernible current	mA	28.2	28.9	29.7	_
Resolution	μΑ	_	7	_	_
Worst case offset and gain error	μΑ	_	_	±743	I <sub>Measure</sub> = 28.9 mA
Non-linearity	μΑ	_	_	±42	_
Input impedance	Ω	197	200	202	No pull up or pull down



# **CAN shield and analog input**

#### CAN Shield

Description	Unit	Minimum	Typical	Maximum	Comment
Input impedance	_	_	0.68μF+1Ω	_	_

# Analog input

Description	Unit	Minimum	Typical	Maximum	Comment
Minimum discernible voltage	V	_	_	0.03	_
Maximum discernible voltage	V	5.64	5.78	5.92	_
Resolution	mV	_	1.4	_	_
Worst case offset and gain error	V	_	_	±0.14	V <sub>Measure</sub> = 5.78 V
Non-linearity	mV	_	_	±8.5	_
Input impedance	kΩ	230	233	236	

## **Digital output**

## Low side digital output

Description	Unit	Minimum	Typical	Maximum	Comment
Voltage	V	0	_	Vin	lout = 500mA
Current	mA	0	_	500	_

#### **CAN** communication

Description	Unit	Minimum	Typical	Maximum	Comment
Available Baud rates	kbps		50		With 120 Ω termination.
			100		The default baud rate is 250
			125		kbps.
			250		
			500		
			1000		
Maximum input voltage range	V	-27	_	40	CAN+ and CAN-

Software updates using CG150 are supported via CAN0 and CAN1 channels.

16 | © Danfoss | October 2021



# **USB** communication

Description	Unit	Minimum	Typical	Maximum	Comment
Available Baud rates	Mbps	12	_	480	_
Maximum input voltage	V	-0.3	_	7.3	D+, D-, and VBUS
USB current limitation	mA		250		

#### **RS232 communication**

Description	Unit	Minimum	Typical	Maximum	Comment
Available Baud rates	bps	_	9600	_	
			11400		
			19200		
			28800		
			38400		
			57600		
			115200		
Maximum input voltage	V	-25	_	25	Rx
		-13.2	_	13.2	Tx

#### **Sensor output**

Description	Unit	Minimum	Typical	Maximum	Comment
Sensor Output Voltage (5V)	V	4.85	5	5.15	
Sensor Output Voltage (8V)	V	7.75	8	8.25	
Sensor Output Current (5V)	mA			250	
Sensor Output Current (8V)	mA			150	

## Video power

Description	Unit	Minimum	Typical	Maximum	Comment
Output Voltage (12V)	V		12		
Output Voltage (24V)	V		24		
Output Current (12V)	mA			750	
Output Current (24V)	mA			375	

## Officially validated digital camera formats

IP Transport Protocol	RTSP, RTP
Video Stream Format	H264, MJPEG



# Officially validated analog camera formats

Format	Lines	Fields	FSC (MHz)
NTSC-M	525	60	3.579545
NTSC-Japan	525	60	3.579545
PAL-B, G, N	625	50	4.433619
PAL-D	625	50	4.433619
PAL-H	625	50	4.433619
PAL-I	625	50	4.433619
PAL-M	525	60	3.575612
PAL-CN	625	50	3.582056
SECAM	625	50	4.406 / 4.25
PAL-60	525	60	4.433619
NTSC (4.43)	525	60	4.433619

#### **Ethernet**

Symbol	Description	Unit	Minimum	Typical	Maximum	Comment
Baud	Available baud rates	bps		10 M 100 M		Automatic polarity detection and correction; Auto- negotiation
V <sub>in</sub>	Max input voltage range	V	-25		25	Receiver input

## **Audio outputs**

Symbol	Description	Unit	Minimum	Typical	Maximum	Comment
HP Out	Output Power	mW		62.5		@1kHz

Right and left channel included - Stereo output



# Wifi / Bluetooth

## Available WiFi frequencies

2.412 to 2.462 GHz 11 Channels				5.180 to 5.240 GHz 7 Channels (U-NII-1)			
	Fre	equency			Fr	equency	
Channel	Center (MHz)	Min (MHz)	Max (MHz)	Channel	Center (MHz)	Min (MHz)	Max (MHz)
1	2412	2401	2423	36	5180	5170	5190
2	2417	2406	2428	38	5190	5170	5210
3	2422	2411	2433	40	5200	5190	5210
4	2427	2416	2438	42	5210	5170	5250
5	2432	2421	2443	44	5220	5210	5230
6	2437	2426	2448	46	5230	5210	5250
7	2442	2431	2453	48	5240	5230	5250
8	2447	2436	2458				•
9	2452	2441	2463				
10	2457	2446	2468				
11	2462	2451	2473				

# Note for the EU region: 5GHz U-NII-1 band is restricted to in-cab applications only

Description	Unit	Minimum	Typical	Maximum	Comment
Transmit Power (802.11b)	dBm		10.5		
Transmit Power (802.11g/n)	dBm		11		
Transmit Power (802.11a/n)	dBm		13		



## **Product ratings**

## DM1x00 environmental testing criteria

#### Climate environment

Description	Applicable standard	Comment
Storage temperature	IEC 60068-2-1, test Ab, IEC 60068-2-2 test Bb	
Operating temperature	IEC 60068-2-1, test Ab, IEC 60068-2-2 test Bd	
Thermal and humidity cycle	IEC 60068-2-38 (partial)	
Degree of protection	IEC 60529	

## Chemical environment

Description	Applicable standard	Comment
Chemical resistance	ISO 16750-5	

#### Mechanical environment

Description	Applicable standard	Comment
Vibration	IEC 60068-2-64 test Fh	3.17g
Bump	IEC 60068-2-27 test Eb	
Shock	IEC 60068-2-27 test Ea	50g
Free fall	IEC 60068-2-31 test Ed	

#### Electrical/electromagnetic

Description	Applicable standard	Comment	
EMC emissions	ISO 13766	Electromagnetic compatibility for earth moving machinery.	
EMC immunity	ISO 13766	Electromagnetic compatibility for earth moving machinery.	
ESD	EN61000-4-2		
Electrical transients	ISO 7637-2, ISO 7637-3		
Short circuit protection	Danfoss test	Inputs and outputs survive continuous short circuit. Normal function resumes when short is removed.	
Reversed polarity protection	Danfoss test	Survives reverse polarity at supply voltage for at least five minutes.	

## Supply voltage/maximum current ratings

DM1x00 displays are designed to operate with a nominal 9 to 36 Vdc power supply with reverse polarity protection.

## Supply voltage/maximum current ratings

Description	Unit	Minimum	Typical	Maximum	Comment
Operating temperature	°C	-30	_	+70	
Storage temperature	°C	-40	_	+85	



#### **Product ratings**

Supply voltage/maximum current ratings (continued)

Description	Unit	Minimum	Typical	Maximum	Comment
DC supply voltage	V	9	_	36	Normal operation.
		6	_	_	Cranking; reduced functionality.
		-36	_	36	Short circuit and reversed polarity protection.
DM1000 variants	A	_	1.7	_	Vin = 9V
		_	1	_	Vin = 14V
		_	0.45	_	Vin = 27V
		_	0.3	_	Vin = 36V
DM1200 variants	Α	<u> </u>	2.8	_	Vin = 9V
		_	1.4	_	Vin = 14V
		_	0.75	_	Vin = 27V
		_	0.5	_	Vin = 36V
+5V output voltage	V	4.75	5	5.09	Normal operation over temperature.
		0	_	36	Short circuit protection.
+5V output current	mA	-	_	100	
Short circuit pin voltage	V	0	_	36	All DEUTSCH connector pins.

To achieve operation at the lowest supply voltage range, Danfoss has the following recommendations:

- **1.** Use the largest appropriate gauge wire for power and ground to reduce cabling voltage drops.
- 2. Disable unused peripherals (WiFi, Bluetooth, GNSS, etc).
- 3. Reduce the overall power requirements on the device.
  - Reduce the LCD back light intensity.
  - Reduce the button back light intensity.
  - Reduce the load on USB Host (C3p03).
  - Reduce the load on sensor power (C1p08).


#### **Ingress Protection (IP) rating**

DM1x00 displays carry Ingress Protection rating of IP66 and IP67 in the front and back.




## **DM1x00 Series Displays dimensions**


Dimensions in mm [in], RAM mount and connector call outs



#### **Button options**

Standard (left) and Navigation (right) button options







# Pin assignments C1—C9

#### C1—DEUTSCH DTM06-12SA

Pin	Name
1	Battery Ground
2	Battery Power
3	CAN0+
4	CANO-
5	Digln/Anln/CAN Shield
6	CAN1+
7	CAN1-
8	+5V SNSR
9	Ignition Input (K15)
10	Multifunction input (DigIn/AnIn/Freq/4-20 mA/Rheostat)
11	Multifunction input (DigIn/AnIn/Freq/4-20 mA/Rheostat)
12	DigOut

## C2—DEUTSCH DTM06-12SB

Pin	Name
1	Sensor Ground
2	DigOut
3	CAN2+
4	CAN2-
5	Digln/Anln/CAN Shield
6	CAN3+
7	CAN3-
8	Multifunction input (DigIn/AnIn/Freq/4-20 mA/Rheostat)
9	Multifunction input (DigIn/AnIn/Freq/4-20 mA/Rheostat)
10	Wake Input (DigIn)
11	DigOut
12	DigOut

# C3—USB Device M12 4 Pin, Male, 'A' key

Pin	Name
1	Device Data +
2	Device Data -
3	Host Vbus
4	Ground

## C4—USB Host M12 4 Pin, Male, 'D' Code

Pin	Name
1	Host Data +
2	Host Data -
3	Host Vbus
4	Ground

© Danfoss | October 2021



#### C5—GNSS Antenna SMA Coaxial

Description	Name
Threads	Ground
Pin	Signal

Ensure the connections are secured properly to avoid signal degradation.

## C6—Video M12 5 Pin, 'A' Code

Pin	Name
1	Pwr Ground
2	Pwr Supply
3	Signal In 1
4	Signal Ground
5	Signal In 2

## C7—Video M12 5 Pin, 'A' Code

Pin	Name
1	Pwr Ground
2	Pwr Supply
3	Signal In 3
4	Signal Ground
5	Signal In 4

## C8—Ethernet M12 4 Pin, 'D' Code

Pin	Name
1	TxD+
2	RxD+
3	TxD-
4	RxD-

## C9—RS232/Stereo M12 8 Pin, 'A' Code


Pin	Name
1	TxD
2	RxD
3	Ground
4	Manufacturing Use Only (Leave Floating)
5	Left Channel
6	Right Channel
7	Ground
8	NC NC

24 | © Danfoss | October 2021



# **Standard Mount**

Standard mounting procedure



Call out	Description
1	Panel gasket (self sticks to housing, stays put during installation)
2	Mounting panel
3	Panel mounting kit
4	External tooth lock washers x 4
5	Fasting screws: 4xM5x0.8 thread type
6	Mounting hole depth: 12 mm [0.47 in] deep Torque: 4.5 N-m [39.8 in-lbs]


# Panel mounting kit

Quantity	Description
4	Screws
4	Washers
1	Gasket
1	Bracket



## **Mounting panels cutouts**


Panels cutouts with dimensions in mm [in]



A	Panel cutout for DM1000 without buttons
В	Panel cutout for DM1000 with buttons
С	Panel cutout for DM1200

#### **RAM** mount

#### Ram mounting procedure



#### RAM mount parts

Call out	Description
1	RAM post mount hole pattern
2	Ball size: 38 mm [1.5 in] Size C
3	External tooth lock washers x 4
4	RAM fastening screws: 4xM5x0.8 thread type Mounting hole depth: 11 mm [0.43 in] deep Torque: 4.5 N-m [39.8 in-lbs].

#### **Fastening**

#### 0

#### Caution

- Use of non-recommended screws can cause damage to housing.
- Reassembly with self-tapping screws can damage existing threads in housing..
- Ensure the vent is not covered. This excludes the RAM mount option.



## Visibility and viewing radius

Due to the display nature of the TFT-LCD screen, the optimal viewing angle for the DM1x00 series displays are at a maximum radius of 85° from either side of the screen.

#### Optimal viewing angle



## Display faulty application recovery

The boot loader is always executed when the unit is powered. The boot loader checks if the application has the completely downloaded flag set and in that case starts to execute it after a delay of 200 ms. The delay gives an opportunity for the PLUS+1° Service Tool to prevent the call to the application. This allows a non functional application to be replaced by the boot loader. This recovery function is activated by the **Communication** > **Recover ECU** menu in the PLUS+1° Service Tool.

#### Cleaning

Do not pressure wash. Clean using a dry, soft, lint-free cloth, such as a micro-fiber cloth.



#### Products we offer:

- Cartridge valves
- DCV directional control valves
- · Electric converters
- · Electric machines
- · Electric motors
- Gear motors
- Gear pumps
- Hydraulic integrated circuits (HICs)
- · Hydrostatic motors
- Hydrostatic pumps
- Orbital motors
- PLUS+1® controllers
- PLUS+1® displays
- PLUS+1\* joysticks and pedals
- PLUS+1® operator interfaces
- PLUS+1® sensors
- PLUS+1® software
- PLUS+1° software services, support and training
- Position controls and sensors
- PVG proportional valves
- Steering components and systems
- Telematics

**Hydro-Gear** www.hydro-gear.com

**Daikin-Sauer-Danfoss** www.daikin-sauer-danfoss.com **Danfoss Power Solutions** is a global manufacturer and supplier of high-quality hydraulic and electric components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market as well as the marine sector. Building on our extensive applications expertise, we work closely with you to ensure exceptional performance for a broad range of applications. We help you and other customers around the world speed up system development, reduce costs and bring vehicles and vessels to market faster.

Danfoss Power Solutions – your strongest partner in mobile hydraulics and mobile electrification.

#### Go to www.danfoss.com for further product information.

We offer you expert worldwide support for ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide you with comprehensive global service for all of our components.

Local address:

Danfoss Power Solutions (US) Company 2800 East 13th Street Ames, IA 50010, USA Phone: +1 515 239 6000 Danfoss Power Solutions GmbH & Co. OHG Krokamp 35 D-24539 Neumünster, Germany

Phone: +49 4321 871 0

Danfoss Power Solutions ApS Nordborgvej 81 DK-6430 Nordborg, Denmark Phone: +45 7488 2222 Danfoss Power Solutions Trading (Shanghai) Co., Ltd. Building #22, No. 1000 Jin Hai Rd Jin Qiao, Pudong New District Shanghai, China 201206 Phone: +86 21 2080 6201

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.