

RRC


Rotary actuator

Oscillation/rotation drive

Size 8/32/63

Overview

This is a compact rack and pinion rotary actuator. Torque: 0.7, 3.1, 5.6 N·m



CONTENTS

Series variation	1284
Product introduction	1284
● Rack & pinion (RRC)	1286
Selection guide	1292
⚠ Safety precautions	1294


The cylinder switches T2YH, T2YV, T3YH, and T3YV are scheduled for end of production at the end of December 2023.

LCM
LCR
LCG
LCW
LCX
STM
STG
STS/STL
STR2
UCA2
ULK*
JSK/M2
JSG
JSC3/JSC4
USSD
UFCD
USC
UB
JSB3
LMB
LML
HCM
HCA
LBC
CAC4
UCAC2
CAC-N
UCAC-N
RCS2
RCC2
PCC
SHC
MCP
GLC
MFC
BBS
RRC
GRC
RV3*
NHS
HRL
LN
Hand
Chuk
MechHnd/Chuk
ShkAbs
FJ
FK
SpdContr
Ending

Series variation

Rotary actuator RRC Series


- LCM
- LCR
- LCG
- LCW
- LCX
- STM
- STG
- STS/STL
- STR2
- UCA2
- ULK*
- JSK/M2
- JSG
- JSC3/JSC4
- USSD
- UFCD
- USC
- UB
- JSB3
- LMB
- LML
- HCM
- HCA
- LBC
- CAC4
- UCAC2
- CAC-N
- UCAC-N
- RCS2
- RCC2
- PCC
- SHC
- MCP
- GLC
- MFC
- BBS
- RRC**
- GRC
- RV3*
- NHS
- HRL
- LN
- Hand
- Chuk
- MecHnd/Chuk
- ShkAbs
- FJ
- FK
- SpdContr
- Ending

Variation	Model No. JIS symbol	Size	Effective torque (0.5 MPa) (N·m)	Max. oscillating angle (°)	
				90	
Rack and pinion		8	0.7	●	
		32	3.1		
		63	5.6		

Product introduction

● Max. oscillating angle 270°
 Torques of 0.7, 3.1, 5.6 N·m (working pressure 0.5 MPa) and oscillating angles of 90°, 180°, 270°, are included in the series.
 Select the ideal model for your application.

● Space saving
 Compact and thin design permits installation in a narrow space.



● Stable torque/long service life
 Uses a unique mechanism combining two linear cylinders with rack and pinion gears. Torque is stable even at low pressure, and internal/external leakages are the same as that of the linear cylinder. Furthermore, long service life is achieved.

● Cushion needle direction can be changed
 RRC-32 and 63 only are 3-directional.

● No lubrication
 No-lubrication usage is possible.
 Total operation costs will be reduced.

● Cushion provided as standard
 Rubber cushion or air cushion is provided as standard.

●: Standard, ◎: Option, ○: Made to order, ■: Not available

Max. oscillating angle (°)			Option		Switch	Page
			Adjustable angle	Copper and PTFE free		
	180	270	A	P6		
	●	●	◎	◎	◎	1286

- LCM
- LCR
- LCG
- LCW
- LCX
- STM
- STG
- STS/STL
- STR2
- UCA2
- ULK*
- JSK/M2
- JSG
- JSC3/JSC4
- USSD
- UFCD
- USC
- UB
- JSB3
- LMB
- LML
- HCM
- HCA
- LBC
- CAC4
- UCAC2
- CAC-N
- UCAC-N
- RCS2
- RCC2
- PCC
- SHC
- MCP
- GLC
- MFC
- BBS
- RRC**
- GRC**
- RV3***
- NHS
- HRL
- LN
- Hand
- Chuk
- MechHnd/Chuk
- ShkAbs
- FJ
- FK
- SpdContr
- Ending



Rotary actuator Rack & pinion

RRC Series

- Size: 8/32/63
- Oscillating angle: 90°/180°/270°

JIS symbol



Specifications

Item	RRC		
Size	8	32	63
Effective torque ^{*1} N·m	0.7	3.1	5.6
Actuation	Rack and pinion mechanism		
Working fluid	Compressed air		
Max. working pressure MPa	1.0 (≈150 psi, 10 bar)		
Min. working pressure ^{*2} MPa	0.1 (≈15 psi, 1 bar)		
Proof pressure MPa	1.6 (≈230 psi, 16 bar)		
Ambient temperature °C	-10 (14°F) to 60 (140°F) (no freezing)		
Port size	Rc1/8		
Oscillating angle tolerance °	90 ⁺⁸ ₋₁ , 180 ⁺⁸ ₋₁ , 270 ⁺⁸ ₋₁		
Cushion	Rubber cushion	Air cushion	
Effective cushion length mm	-	4.8	5.8
Allowable absorbed energy J	0.05	0.21	0.41
Volumetric capacity cm ³	90°	3	12
	180°	6	24
	270°	9	36
Lubrication	Not required (use turbine oil ISO VG32 if necessary for lubrication)		

*1 : Effective torque value is at working pressure 0.5 MPa.

*2 : When using RRC-8 with max. oscillating angle, the working pressure is to be 0.3 MPa and over.


*3 : Adjustable angle is available as an option. Refer to page 1291.

Max. load

Use the load applied to the shaft at the values below or less.

Unit: N

Model No.	RRC-8	RRC-32	RRC-63
Thrust load F1	9.8	39.2	58.8
Radial load F2	19.6	78.4	117.6



Switch specifications

- 1-color/2-color display

Item	Proximity 2-wire		Proximity 2-wire				Proximity 3-wire				Reed 2-wire					
	T1H/T1V	T2H/T2V	T2YH/T2YV	T2WH/T2WV	T3H/T3V	T3PH/T3PV	T3YH/T3YV	T3WH/T3WV	T0H/T0V	T5H/T5V		T8H/T8V				
Applications	For programmable controller, relay, compact solenoid valve	Dedicated for programmable controller				For programmable controller, relay				For programmable controller, relay	For programmable controller, relay, I/C circuit (no indicator lamp), serial connection		For programmable controller, relay			
Output method	-				NPN output	PNP output	NPN output	NPN output	-							
Pwr. supp. V.	-				10 to 28 VDC				-							
Load voltage	85 to 265 VAC	10 to 30 VDC	24 VDC ±10%		30 VDC or less				12/24 VDC	100/110 VAC	5/12/24 VDC	100/110 VAC	12/24 VDC	110 VAC	220 VAC	
Load current	5 to 100 mA	5 to 20 mA (*3)				100 mA or less	50 mA or less		5 to 50 mA	7 to 20 mA	50 mA or less	20 mA or less	5 to 50 mA	7 to 20 mA	7 to 10 mA	
Indicator lamp	LED (Lit when ON)	LED (Lit when ON)	Red/green LED (Lit when ON)	Red/green LED (Lit when ON)	LED (Lit when ON)	Yellow LED (Lit when ON)	Red/green LED (Lit when ON)	Red/green LED (Lit when ON)	LED (Lit when ON)		Without indicator lamp		LED (Lit when ON)			
Leakage current	≤1 mA at 100 VAC, ≤2 mA at 200 VAC	1 mA or less				10 µA or less				0 mA						
Weight g	1 m: 33	1 m:18	1 m: 33	1 m:18	1 m:18	1 m: 33	1 m:18	1 m:18	1 m:18		1 m: 33					
	3 m: 87	3 m:49	3 m: 87	3 m:49	3 m:49	3 m: 87	3 m:49	3 m:49	3 m:49		3 m: 87					
	5 m:142	5 m:80	5 m:142	5 m:80	5 m:80	5 m:142	5 m:80	5 m:80	5 m:80		5 m:142					

*1 : Refer to Ending Page 1 for detailed switch specifications and dimensions.

*2 : Switches other than the above models, such as switches with connectors, are also available. Refer to Ending Page 1.

*3 : The max. load current is 20 mA at 25°C. The current is lower than 20 mA if the operating ambient temperature around the switch is higher than 25°C. (5 to 10 mA at 60°C)

Cylinder weight

Unit: kg

Oscillating angle	Model No.	90°	180°	270°	Switch weight (per 1 pc.)	Switch mounting bracket		
						90°	180°	270°
	RRC-8	0.39	0.43	0.49	Refer to the weight in the switch specifications.	0.005		
	RRC-32	1.02	1.23	1.45		0.011	0.013	0.015
	RRC-63	1.68	2.03	2.37		0.012	0.014	0.016

(Example) Product weight of RRC-8-90-T2H-D

Body weight..... 0.39 kg
 Switch weight..... 0.018 2 pcs. = 0.036 kg
 Switch mounting bracket weight.... 0.005 2 pcs. = 0.010 kg
 Product weight 0.39 kg + 0.036 kg + 0.010 kg = 0.436 kg

How to order

Without switch (built-in magnet for switch)



With switch (built-in magnet for switch)



A Size

B Max. oscillating angle

C Switch model No.

* indicates the lead wire length.

D Switch quantity

E Option

[Example of model No.]

RRC-8-90-T2H-R-A

Model: Rotary actuator rack & pinion

- A Size : 8
- B Max. oscillating angle : 90°
- C Switch model No. : Proximity T2H switch, lead wire 1 m
- D Switch quantity : With clockwise rotation detection 1 piece
- E Option : Adjustable angle

Code	Description					
A Size						
Model No.	Effective torque					
8	0.7 [N·m]					
32	3.1 [N·m]					
63	5.6 [N·m]					
B Max. oscillating angle						
90	90°					
180	180°					
270	270°					
C Switch model No.						
Axial lead wire	Radial lead wire	Contact	Voltage		Indicator	Lead wire
			AC	DC		
T0H*	T0V*	Reed	●	●	1-color display	2-wire
T5H*	T5V*		●	●	Without indicator lamp	
T8H*	T8V*		●	●	1-color display	
T1H*	T1V*	Proximity	●		1-color display	2-wire
T2H*	T2V*			●		
T3H*	T3V*			●		
T2WH*	T2WV*			●	2-wire	
T2YH*	T2YV*			●		2-wire
T3WH*	T3WV*			●	3-wire	
T3YH*	T3YV*			●		3-wire
T3PH*	T3PV*		●	1-color display	3-wire	
* Lead wire length						
Blank	1 m (standard)					
3	3 m (option)					
5	5 m (option)					
D Switch quantity						
R	With clockwise rotation detection 1 piece					
L	With counterclockwise rotation detection 1 piece					
D	2					
E Option						
A	Adjustable angle					
P6	Copper and PTFE free					

How to order switch

● Switch body + mounting bracket set (including rail)




Switch model No. (Item C above) Size (Item A above) Max. oscillating angle (Item B above)

● Mounting bracket set (including rail)




Size (Item A above) Max. oscillating angle (Item B above)

● Switch body only



Switch model No. (Item C above)

Torque




LCM
LCR
LCG
LCW
LCX
STM
STG
STS/STL
STR2
UCA2
ULK*
JSK/M2
JSG
JSC3/JSC4
USSD
UFCD
USC
UB
JSB3
LMB
LML
HCM
HCA
LBC
CAC4
UCAC2
CAC-N
UCAC-N
RCS2
RCC2
PCC
SHC
MCP
GLC
MFC
BBS
RRC
GRC
RV3*
NHS
HRL
LN
Hand
Chuk
MechHnd/Chuk
ShkAbs
FJ
FK
SpdContr


Ending

Internal structure and parts list

● Standard



● With switch



No.	Part name	Material	Remarks	No.	Part name	Material	Remarks
1	Cap (2)	Aluminum alloy		16	Bearing	—	
2	Cap gasket	Nitrile rubber		17	Cover	Aluminum alloy	
3	Body	Aluminum alloy		18	Shaft	Steel	
4	Piston	Stainless steel		19	Key	Steel	
5	Magnet	Plastic		20	Cushion rubber	Urethane rubber	RRC-8 only
6	Piston packing	Nitrile rubber		21	DU bush	—	RRC-8 only
7	Wear ring	Acetal resin		22	Switch	—	
8	Cushion packing	Nitrile rubber	Excluding RRC-8	23	Stop plate	Stainless steel	
9	Needle	Copper alloy	Excluding RRC-8	24	Phillips pan head machine screw/captive washer	Steel	
10	Needle gasket	Nitrile rubber	Excluding RRC-8	25	Fixing nut	Stainless steel	
11	Cap (1)	Aluminum alloy		26	Switch rail	Aluminum alloy	
12	U nut	Steel	Excluding RRC-8	27	Hexagon socket set screw	Steel	
13	Hexagon socket set screw	Alloy steel					
14	Phillips flat head machine screw	Steel					
15	Hexagon socket head cap screw	Alloy steel					

Repair parts list


Model No.	Kit No.	Repair parts No.
RRC-8	RRC-8K	2 6 7
RRC-32	RRC-32K	2 6 7 8 10
RRC-63	RRC-63K	2 6 7 8 10

Note: Specify the kit No. when placing an order.

Dimensions




● RRC-8



Code	A		
	Oscillating angle		
Model No.	90°	180°	270°
RRC-8	94	109	124

● With RRC-8 switch



Code	A			RD																	
	Oscillating angle			T1*			T2*/T3*			T0*/T5*			T8*			T2Y*/T3Y*			T2W*/T3W*		
	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°
RRC-8	94	109	124	31	36	40	33	37	41	30	37	41	24	31	35	31	36	40	34	39	43

Code	LD																	
	T1*			T2*/T3*			T0*/T5*			T8*			T2Y*/T3Y*			T2W*/T3W*		
	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°
RRC-8	31	36	40	33	37	41	30	37	41	24	31	35	31	36	40	34	39	43


Note: Dimensions other than the above are the same as the type without switch.

- LCM
- LCR
- LCG
- LCW
- LCX
- STM
- STG
- STS/STL
- STR2
- UCA2
- ULK*
- JSK/M2
- JSG
- JSC3/JSC4
- USSD
- UFCD
- USC
- UB
- JSB3
- LMB
- LML
- HCM
- HCA
- LBC
- CAC4
- UCAC2
- CAC-N
- UCAC-N
- RCS2
- RCC2
- PCC
- SHC
- MCP
- GLC
- MFC
- BBS
- RRC**
- GRC**
- RV3***
- NHS
- HRL
- LN
- Hand
- Chuk
- MechHnd/Chuk
- ShkAbs
- FJ
- FK
- SpdContr
- Ending

Dimensions




● RRC-32/63



* The key is attached when shipping.

Code	A			B	C	D	E	F	G	H	I	J	K	L	M	N	P	R	S	T	U	W
	Oscillating angle																					
Model No.	90°	180°	270°																			
RRC-32	153	191	229	84	33	31	20	67	3	44	10	8	13	3	1.8	10	34	29	M5	8	4.5	6
RRC-63	172	216	260	101	38	41.5	21.5	78	4.5	52	12	10	16	4	2.5	13	40	34	M6	9	7	7

● RRC-32/63 with switch



* The key is attached when shipping.

Code	A			RD																	
	Oscillating angle			T1*			T2*/T3*			T0*/T5*			T8*			T2Y*/T3Y*			T2W*/T3W*		
	Model No.	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°
RRC-32	153	191	229	56	66	75	58	67	77	57	67	76	51	61	70	56	66	75	59	69	78
RRC-63	172	216	260	64	75	86	65	76	87	65	76	87	59	70	81	64	75	86	67	78	89


Code	LD																	
	T1*			T2*/T3*			T0*/T5*			T8*			T2Y*/T3Y*			T2W*/T3W*		
	Model No.	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°	270°	90°	180°
RRC-32	56	66	75	58	67	77	57	67	76	51	61	70	56	66	75	59	69	78
RRC-63	64	75	86	65	76	87	65	76	87	59	70	81	64	75	86	67	78	89

Note: Dimensions other than the above are the same as the type without switch.


Dimensions: Option

● Adjustable angle

* The cylinder's oscillating angle will decrease when the angle adjustment hex bolt is rotated clockwise.




L side R side



3 port positions each are provided on the R and L sides, as in the figure above.

Code	D		AA	Allowable absorbed energy J (For adjustable angle single 10°)	Hexagon head bolt dimension for adjustable angle (Common for R and L)
	MIN	MAX			
RRC-8	10.7	11.5	4	0.02	M5×0.5
RRC-32	13.4	15.5	6	0.06	M6×0.75
RRC-63	13.5	16.0	7	0.13	M6×0.75

● Key dimensional drawing



Model No.	Code	A	B	K	D	E
RRC-32		16 ⁰ _{-0.18}	13	1.5	3 ⁰ _{-0.025}	0.2
RRC-63		20 ⁰ _{-0.21}	16	2	4 ⁰ _{-0.030}	0.2

- LCM
- LCR
- LCG
- LCW
- LCX
- STM
- STG
- STS/STL
- STR2
- UCA2
- ULK*
- JSK/M2
- JSG
- JSC3/JSC4
- USSD
- UFCD
- USC
- UB
- JSB3
- LMB
- LML
- HCM
- HCA
- LBC
- CAC4
- UCAC2
- CAC-N
- UCAC-N
- RCS2
- RCC2
- PCC
- SHC
- MCP
- GLC
- MFC
- BBS
- RRC**
- GRC**
- RV3*
- NHS
- HRL
- LN
- Hand
- Chuk
- MechHnd/Chuk
- ShkAbs
- FJ
- FK
- SpdContr
- Ending

Selection guide of rotary actuator

Step 1 Oscillating time check

Use an oscillating time within the specified range of the table below.


Unit: S

Oscillating angle (degree)	90	180	270
Model No.			
RRC-8	0.015 to 0.151	0.030 to 0.302	0.045 to 0.452
RRC-32	0.038 to 0.377	0.075 to 0.754	0.113 to 1.131
RRC-63	0.073 to 0.440	0.147 to 0.880	0.220 to 1.320

* The oscillating time in the table is the time for the oscillating to end after movement begins.

Step 2 Size selection

● When simple static pushing force is required for clamp, etc.



Step 3 Check of allowable energy

When using an inertial load, keep the load energy lower than the rotary actuator's allowable energy.

- (1) Angular speed at oscillation edge $\omega = \frac{2\theta}{t} (\text{rad}/\text{s})$
 θ : Oscillating angle (rad) t : Oscillating time (s)

- (2) Calculation of load inertia energy
 $E = \frac{1}{2} \times I \times \omega^2 (\text{J})$
 I : Load moment of inertia ($\text{kg}\cdot\text{m}^2$)

- (3) Confirm that the load inertia energy E is equal to or less than the allowable energy of the rotary actuator.

When exceeding the allowable energy, an external shock absorber, etc., will be required.

Figure for moment of inertia calculation

● When rotary shaft passes through the workpiece

Shape	Sketch	Requirements	Moment of inertia I kg·m ²	Radius of rotation K _i ²	Remarks
Dial plate		<ul style="list-style-type: none"> ● Diameter d(m) ● Weight M(kg) 	$I = \frac{Md^2}{8}$	$\frac{d^2}{8}$	<ul style="list-style-type: none"> ● No mounting direction ● For sliding use, contact CKD.
Circular stepped plate		<ul style="list-style-type: none"> ● Diameter d₁(m) ● Diameter d₂(m) ● Weight d₁ section M₁(kg) ● Weight d₂ section M₂(kg) 	$I = \frac{1}{8} (M_1d_1^2 + M_2d_2^2)$	$\frac{d_1^2 + d_2^2}{8}$	<ul style="list-style-type: none"> ● Ignore when the d₂ section is extremely small compared to the d₁ section
Bar (center of rotation at end)		<ul style="list-style-type: none"> ● Bar length R(m) ● Weight M(kg) 	$I = \frac{MR^2}{3}$	$\frac{R^2}{3}$	<ul style="list-style-type: none"> ● Mounting direction is horizontal ● Oscillating time changes when the mounting direction is vertical
Thin rod		<ul style="list-style-type: none"> ● Bar length R₁ ● Bar length R₂ ● Weight M₁ ● Weight M₂ 	$I = \frac{M_1/R_1^2}{3} + \frac{M_2/R_2^2}{3}$	$\frac{R_1^2 + R_2^2}{3}$	<ul style="list-style-type: none"> ● Mounting direction is horizontal ● Oscillating time changes when the mounting direction is vertical
Bar (center of rotation at center of gravity)		<ul style="list-style-type: none"> ● Bar length R(m) ● Weight M(kg) 	$I = \frac{MR^2}{12}$	$\frac{R^2}{12}$	<ul style="list-style-type: none"> ● No mounting direction
Thin rectangle plate (rectangular parallellepip)		<ul style="list-style-type: none"> ● Plate length a₁ ● Side length a₂ ● Side length b ● Weight M₁ ● Weight M₂ 	$I = \frac{M_1}{12} (4a_1^2 + b^2) = \frac{M_2}{12} (4a_2^2 + b^2)$	$\frac{(4a_1^2 + b^2) + (4a_2^2 + b^2)}{12}$	<ul style="list-style-type: none"> ● Mounting direction is horizontal ● Oscillating time changes when the mounting direction is vertical
Rectangular parallellepip		<ul style="list-style-type: none"> ● Side length a(m) ● Side length b(m) ● Weight M(kg) 	$I = \frac{M}{12} (a^2 + b^2)$	$\frac{a^2 + b^2}{12}$	<ul style="list-style-type: none"> ● No mounting direction ● For sliding use, contact CKD.

Concentrated load		<ul style="list-style-type: none"> ● Shape of concentrated load ● Length to center of gravity of concentrated load R₁(m) ● Arm length R₂(m) ● Concentrated load weight M₁(kg) ● Arm weight M₂(kg) 	$I = M_1(R_1^2 + k_i^2) + \frac{M_2R_2^2}{3}$	Calculate k _i ² according to shape of concentrated load	<ul style="list-style-type: none"> ● Mounting direction is horizontal ● When M₂ is extremely small compared to M₁, it may be calculated as M₂ = 0
-------------------	--	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------	-------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

How to convert load J_L to rotary actuator shaft rotation when using with gear

Gear		<ul style="list-style-type: none"> ● Gear - Rotary side (tooth number) a, Load side (tooth number) b ● Load moment of inertia N·m 	Load moment of inertia for the rotary actuator's shaft rotation	$I_H = \left(\frac{a}{b}\right)^2 J_L$	<ul style="list-style-type: none"> ● When gear shape is larger, gear moment of inertia should be considered.
------	--	-----------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------	----------------------------------------	-----------------------------------------------------------------------------------------------------------------------------

LCM
LCR
LCG
LCW
LCX
STM
STG
STS/STL
STR2
UCA2
ULK*
JSK/M2
JSG
JSC3/JSC4
USSD
UFCD
USC
UB
JSB3
LMB
LML
HCM
HCA
LBC
CAC4
UCAC2
CAC-N
UCAC-N
RCS2
RCC2
PCC
SHC
MCP
GLC
MFC
BBS
RRC
GRC
RV3*
NHS
HRL
LN
Hand
Chuk
MechHnd/Chuk
ShkAbs
FJ
FK
SpdContr
Ending



Safety Precautions

Be sure to read this section before use.

Refer to Intro Page 73 for general information of the cylinder, and to Intro Page 80 for general information of the cylinder switch.

Product-specific cautions: Rotary actuator rack and pinion mechanism RRC Series

Design/selection

CAUTION

■ Do not apply torque exceeding rated output externally to the product.

If force exceeding rated output is applied, the product could be damaged.

■ If oscillating angle repeatability is required, directly stop external load.

The initial oscillating angle may change even with products provided with adjustable angles.

■ If the axial load (thrust load) on the shaft exceeds the allowable value, faulty operation could occur.

Therefore, do not apply a load in excess of the allowable value. If this is unavoidable, use a structure with a thrust bearing as shown in Fig. 1.




Fig. 1

■ Avoid applying bending (radial) load exceeding the allowable value onto the shaft end, or faulty operation could occur.

When unavoidable, use a mechanism transmitting only rotation as shown in Fig. 2.

When connecting the shaft end and load at any position in the oscillation range, use flexible couplings, etc., that will not twist off to prevent the shaft from breaking and bearings from wearing or seizing.




Fig. 2 Radial load


■ Install the external stopper in a position far from the rotary shaft.

If the stopper is installed near the rotary shaft, torque generated by the product could be applied to the rotary shaft. This reaction on the stopper may damage the rotary shaft or bearings, possibly resulting in injury to the operator or damage to equipment or devices.

■ If the load weight is large and oscillation speed is high, large inertia could be generated and allowable absorbed energy exceeded, possibly damaging the rotary actuator.

Install a shock absorber to absorb inertia.

■ When installing a load or jig, etc., on the rotary actuator shaft, check that load is not applied to the body as shown in Fig. 3.



OK X

Fig. 3

■ Prevent seizing at rotating sections.

Apply grease to rotating sections (pins, etc.) to prevent seizing.

■ The retention torque of the oscillating end is about half that of the effective torque, so a load factor of 50% or less should be used.

■ Generally, select the model so that the output torque is twice or more than that required by load. The RRC Series uses a double piston, so if the oscillating angle is adjusted by the stopper bolt, torque at the oscillation end will be half the effective torque.

■ Even if the required torque load is low during oscillation motion, the load inertia may lead to actuator damage. Upon consideration of moment of inertia, kinetic energy and oscillating time, be sure to use with the allowable energy or less.

LCM
LCR
LCC
LCW
LCC
STM
STG
STS/STL
STR2
UCA2
ULK*
JSK/M2
JSG
JSC3/JSC4
USSD
UFCD
USC
UB
JSB3
LMB
LML
HCM
HCA
LBC
CAC4
UCAC2
CAC-N
UCAC-N
RCS2
RCC2
PCC
SHC
MCP
GLC
MFC
BBS
RRC
GRC
RV3*
NHS
HRL
LN
Hand
Chuk
MecHnd/Chuk
ShkAbs
FJ
FK
SpdContr
Ending

Mounting, installation and adjustment


⚠ CAUTION

- When adjusting the angle by supplying pressure, do not rotate the device too much in advance.
When adjusting while supplying pressure, the device could rotate and drop during adjustment, depending on how it is oriented, possibly resulting in operator, component, or device injury or damage.
- Do not loosen the angle adjustment hexagon bolt beyond the adjusting range.
Loosening more than the adjusting range may cause the angle adjustment bolt to fall out, potentially causing bodily injury or damage to the workpiece/device/equipment. The cylinder's oscillating angle will decrease when the angle adjustment hexagon bolt is rotated clockwise.


- Observe steps (1) to (5) when adjusting the angle. If adjustments are not made this way, the seal washer will be damaged after one or two adjustments.

[Angle adjustment procedure]


- (1) First loosen the hexagon nut as shown in Fig. 1.




- (2) Second, remove the seal washer cap (2) by hand to reach the state shown in Fig. 2.




- (3) Turn the angle adjustment hexagon bolt, hexagon nut, and seal washer together as shown in Fig. 3, and adjust the angle. Check that the rubber section of the seal washer does not bite into the thread part.



- (4) After adjusting the angle, move the seal washer near to the cap (2) by hand as shown in Fig. 4.



- (5) Tighten securely with the hexagon nut as shown in Fig. 5. Check that the rubber section of the seal washer does not bite into the thread part.



- Securely tighten the hexagon nut after adjusting the angle. If not adequately tightened, the hex nut could loosen in the course of usage, resulting in external leakage.

LCM
LCR
LCG
LCW
LCX
STM
STG
STS/STL
STR2
UCA2
ULK*
JSK/M2
JSG
JSC3/JSC4
USSD
UFCD
USC
UB
JSB3
LMB
LML
HCM
HCA
LBC
CAC4
UCAC2
CAC-N
UCAC-N
RCS2
RCC2
PCC
SHC
MCP
GLC
MFC
BBS
RRC
GRC
RV3*
NHS
HRL
LN
Hand
Chuk
MechHnd/Chuk
ShkAbs
FJ
FK
SpdContr
Ending