

OIL COOLING UNIT

AKJ9 SERIES

Immersion type

AKC9 SERIES

Circulating type





OIL COOLING UNIT

Overview / Features

Immersion-type oil cooling unit mounted directly on the coolant tank

It is a cooler that is placed on the coolant tank and cools the fluid inside the tank directly with a cooling coil.

* The circulation pump is not provided as an accessory and must be prepared separately by the customer.


High-accuracy model with the inverter-controlled compressor

The coolant temperature can be controlled within ±0.1°C over the entire cooling load range (from 0 to 100% load) and this helps to increase the accuracy of machine tools.

Installation compatibility

with conventional

products is secured.





Further downsizing the industry's top-class compact design

* Comparison in the AKJ459 class (units: mm)



Enhanced support for shallow tanks with reduced cooling coil depth




 Cooling coil height comparisor AKJZ188 350 AKJZ358 350 AKJZ458 350 AKJZ568 350 AKJZ908

AKJ189 AKJ359 345 AKJ459 AKJ569 AKJ909

The cooling capa

Extension of cooling capacity control range


■ ±0.1°C oil temperature control realized over a load range from 0% (no load) to 100%.



Note: Pattern diagram with the heating load stabilized at 0 - 100%

Achieve high energy-saving performance

- Achieve high energy-saving performance with the adoption of a Daikin original IPM motor and R410A refrigerant for high COP characteristics.
- The power consumption can be checked on the operation panel.
- * Comparison taking a non-inverter model to have a power consumption of 100
- Measured during the Daikin model operation pattern





Improved durability/maintainability

 The cooling coil construction suppresses the adhesion and accumulation of cutting/grinding chips.

Increased tolerance of harsh factory conditions including mist and dust

- The ingress protection of the control box has been upgraded (equivalent to IP54).
- Sulfur-free parts have been adopted for electronic components.

Increased tolerance of long-distance transportation

• The specifications for vibration durability during transport have been upgraded to reflect actual transportation conditions.


Predictive maintenance function prevents trouble in advance

- Predictive maintenance function
- A warning signal is output to notify that maintenance is required when the air filter or condenser becomes clogged.
- 3 steps minimizing machine down time
- Step 1 Autonomous compensation of overloaded operation
- Step 2 Notifying the customer about inspection/maintenance by issuing a warning
- Step 3 Continuing operation in an emergency mode, if operation is possible by restricting some functions and specifications

Simple monitoring of operating status

- The room temperature, tank fluid temperature and other internal data can be monitored at a personal computer using Hybrid-Win* Operating status can be grasped easily with one list presenting all the data collectively.
- * Hybrid-Win is a software tool for monitoring the internal status at a personal computer. You can download the tool itself and its instruction manual free of charge from the website (http://www.daikinpmc.com) after registering as a member.

* The communications cable and the monitor harness must be purchased separately



Functions featured

■ Refrigerant gas shortage detection function

When the refrigerant gas leak status occurs (cooling disabled), alarm signals are output.

Prevents damage to the machine and machining defects.

■ Temperature warning function

A warning signal can be output when the targeted fluid temperature or air temperature was out of the arbitrary setting range.

■ Autotuning function

This function substantially minimizes trial operation adjustment time by automatically setting the gain when fluid temperature control is not stable with the factory setting or when optimization is required.


■ 999-hour timer function (ON timer)

The operation start time can be set in a range between 0 and 999 hours (in hour units).

RoHS-compliant

Complies with the RoHS Directive, e.g. by adopting printed circuit boards with lead-free solder.


Four types of optional specification models in addition to the standard model for shorter product delivery terms



Different voltage specifications (-046, -047, -048)


■ The AC 230 V system (-046) has no transformer, while the AC 400 V (-047) and AC 480 V systems (-048) incorporate a transformer inside the product. The installation dimensions and footprint are the same as for the standard models.

Applications



OILCOOLING UNIT | 2





Note: 1. The [_____ enclosure indicates work that needs to be arranged locally.

- 2. The heater is only applicable to AKJ-H.
- 3. The piping system of AKJ1509 differs from that shown in this figure.

■ Refrigerating cycle

- A: Refrigerant gas is converted into compressed gas at high temperature and high pressure by a compressor so that gas can be easily cooled and liquefied by a condenser.
- B: In the condenser, the gas at high temperature and high pressure generated in the compressor is cooled with air and converted into liquid at high temperature and high pressure.
- C: The decompression mechanism (electronic expansion valve) reduces the pressure of the liquid at high temperature and high pressure and converts it into liquid at low temperature and low pressure by throttling it so that it can be easily evaporated in a cooling coil.
- D: In the cooling coil, liquid at low temperature and low pressure generated in the decompression mechanism absorbs heat from the coolant, evaporates (cools the coolant), and is converted into gas at low temperature and low pressure.
- E: The hot gas bypass valve controls the cooling capacity at low loads by adjusting the volume of gas at high temperature and high pressure supplied to the cooling coil.









1 Oil cooling unit identification code

AKJ: High-accuracy inverter controlled oil cooling unit Immersion type for cutting/grinding fluid (oil)

2 Cooling capacity (kW)

18:Cooling capacity 1.8 kW 35:Cooling capacity 4.5 kW 45:Cooling capacity 4.5 kW 90:Cooling capacity 5.6 kW 90:Cooling capacity 15.0 kW

4 Option Symbol

Options and their combinations (Refer to the following table.)

Special specifications

-*** (3-digit number), C*** (3-digit number), etc. Please consult us about detailed information.

3 Symbol of series (Symbol to represent model change)

9: "9" series

■ Options and their combinations

■ AKJ9 (Immersion type)

Option Symbol	With breaker	Compliance with CE	With heater	Different voltage type (1)	Different voltage type (2)	Different voltage type (3)
−B	✓	_	_	_	_	_
-C	_	✓	_	_	_	_
-H	_	_	✓	_	_	_
-046	_	1	_	✓	-	_
-047	✓	_	_	_	✓	_
-048	✓	_	_	_	_	✓
-BC	✓	✓	_	_	_	_
–BH	✓	_	✓	_	_	_
-CH	_	✓	✓	_	_	_
-BCH	✓	✓	✓	_	_	_
-001	✓	_	_	✓	_	_
-002	_	✓	-	✓	_	_
-003	_	_	✓	✓	_	_
-005	✓	✓	_	✓	_	_
-006	✓	_	✓	✓	_	_
-008	_	✓	✓	✓	_	_
-011	✓	✓	✓	✓	_	_
-017	✓	✓	_	_	✓	_
-018	✓	_	✓	_	✓	_
-023	✓	✓	✓	_	✓	_
-032	✓	✓	_	_	_	✓
-033	✓	_	✓	_	_	✓
-038	✓	✓	✓	_	_	✓

Different voltage type (1) Without transformer AC 220, 230 V 50/60 Hz

Different voltage type (2) With transformer AC 380, 400, 415 V 50/60 Hz, With breaker

Different voltage type (3) With transformer AC 440, 460, 480 V 50/60 Hz, With breaker



Specifications

AKJ189, AKJ359, AKJ459



Oil cooling unit ho	orsepowe	r (HP)				.5					.2					.5	
Model name			Standard	-B	-C	J189 –H	Different voltage specifications*3	Standard	-B	AKJ -C	-H	Different voltage specifications*3	Standard	-B	-C	J459 –H	Different voltage specifications*3
Cooling capacity (5	50/60 Hz)	*1 kW			1.6	/1.8	1 -1			3.2	/3.5				4.2	/4.5	
Heater kV				-		1	-		_		1	-		-		1	-
Supply power*2	Main c	ircuit	Three-ph	ase 200/	200•220	VAC 50/60 Hz	*3	Three-ph	nase 200/	200•220	/AC 50/60 Hz	*3	Three-ph	ase 200,	/200•220	VAC 50/60 Hz	*3
Power voltage Operating circuit										DC12	2/24 V						
200 V 50 F				0.82	kW/3.3	Δ			1.37	kW/5.2				1 46	kW/5.6	Δ	
	200 V 60 Hz			kW/3.2		*8			kW/5.1		*8			kW/5.4		*8	
Maximum power consumption/	cooling -	220 V 60 Hz			kW/3.0		-			kW/4.8		-			kW/5.1		1 "
maximum current -		200 V 50 Hz		- 0.03	KVV/3.07	1.20 kW/3.8 A			-	KVV/4.07	1.20 kW/3.8 A	_		-	KVV/5.17	1.20 kW/3.8 A	
consumption	Whon -					1.20 kW/3.8 A	_				1.20 kW/3.8 A	_				1.20 kW/3.8 A	
	heating -	200 V 60 Hz					_				· ·	_				· ·	
		220 V 60 Hz				1.44 kW/4.2 A	-		_		1.44 kW/4.2 A	-				1.44 kW/4.2 A	
Transformer capac	ity				-		2.14 kVA			_		2.14 kVA			-		2.14 kVA
Exterior color										,	white						
External dimension	ns (H×W	×D) mm			920 × 3	60 × 440				1,045 × 3	360 × 440				1,200 × 3	360 × 440	
Compressor (Herm	etic DC s	wing type)		E	quivalen	t to 0.4 kW			Ec	quivalent	to 0.75 kW			Е	quivalen	t to 1.1 kW	
Evaporator										Open c	oil type						
Condenser									(Cross-fin	coil type						
Propeller fan	Motor								54 W								
Agitator			Three phase AC, 60 W, 4 P														
fion	Standa	rd		Room temperature or machine temperature*4 (Set to "Room temperature: Mode 3" by default)													
Temperature 5	Object to	be controlled							Ta	nk fluid t	emperature						
adjust Synchronization K							-9.9 to +	9.9 agair	nst the s	tandard	temperature	(Set at 0.0 b	y default	:)			
(Selectable)	Object to	be controlled									emperature	`	,	,			
Fixed	Range	°C									50						
Oil temperature co		solution								±0.							
Capacity control ra								0 to 100%									
Timer function	90							ON timer: 1 to 999 hours (1-hour unit setting)									
Refrigerant control				Compressor revolutions by inverter + Opening of electric expansion						ansion v	alvo						
Refrigerant (R410A)*	5 Filling an	nount ka		0.55 0.76					I	0.99							
Protection devices			restart p	reventic stat, refri	ernal the on timer, igerant le	rmostat, disc low room ter eakage detec	charge pipe to mperature pro ctor, inverter p t (-C type on	tection to	hermost n device	nostat, co at, high t set, circu	ondenser ter fluid tempera uit breaker (-	ture protection. B type only),	on therm , high-pre	ostat, lo ssure p	-phase p w fluid te ressure :	rotection de emperature p switch (-C ty	rotection pe only),
	tempera	ture °C								5 to	45						
Operating Tank flu	uid temper	ature °C								5 to	50						
Oil vis	cosity	mm²/s								0.5 to	200						
Acceptable fluid						Water-solub	le cutting/gri	-			-	ation oil, hyd ucts, and fue		, indust	rial wate	r	
Operating sound (v measurement in ar (Front 1 m, height	n anechoi									6		,	,				
Transport vibration		ınce		_		Up	and down v	ibration	14.7 m/s	s² (1.5 G)	× 2.5 hr (7.	5 to 100 Hz s	weep/fiv	e min.)			
Protective structure									IP	2X							
Mass kg			38		40	60		44		46	66		50:		52	72	
Molded-case circuit breaker (Rated current)			-	10		-		-	10		-		-	10		-	
Items Molde circuit (Rated	(Rated current) Δ							10 (Re	equired	for types	other than	-B type) *7					
the customer Device	other tha d-case cire	n cuit breaker						Tank,	supply	pump, fl	oat switch, r	eturn filter					

*1. The cooling capacity indicates the value at the standard point (tank fluid temperature: 35°C, room temperature: 35°C, Fluid used: Water for AKJ 1509 / Oil; ISO VG 32 for others). This unit has about $\pm 5\%$ of product tolerance.

*2. Use a commercial power supply for the power source. The use of an inverter power supply may cause burn damage to the machine.

The voltage fluctuation range should be within ±10%. If the voltage fluctuation range is more than ±10%, please consult us.

*3. There are the following three types of different voltage specifications.

AC220, 230 V : Option code –046 (without transformer)

AC380, 400, 415 V : Option code –047 (with built-in transformer)

AC440, 460 V : Option code –048 (with built-in transformer)

The main circuit voltage is the transformer's secondary side voltage of AC 200 V, 50/60 Hz.

(-046 units have no transformer and therefore have the same external dimensions and mass as standard units. Their main circuit voltage is 220/230 VAC, 50/60 Hz.)

- *4. The optional thermistor for machine temperature synchronization is required. (Refer to Page 17 for details.) *5. The SDS (Safety Data Sheet) of refrigerant R410A is attached to the -C type.
- *6. Electric component box ingress protection: IP54 or equivalent (However, use piping conduits etc. rated at least IP54 at wiring ports.)
- *7. The molded-case circuit breaker is not supplied with this product. Please prepare it yourself.
- *8. The maximum power consumption/maximum current consumption of different voltage specifications are shown in the tables below.

AKJ18	89		AKJ359		AKJ459		AKJ569		AKJ909		AKJ1509	
Supply	y power	Power/current	Supply power	Power/current	Supply power	Power/current	Supply power	Power/current	Supply power	Power/current	Supply power	Power/current
220V	50Hz	0.82kW 3.0A	220V 50Hz	1.38kW 4.8A	220V 50Hz	1.46kW 5.1A	220V 50Hz	2.92kW 9.0A	220V 50Hz	3.41kW 10.3A	220V 50Hz	5.38kW 15.8A
2200	60Hz	0.83kW 3.0A	60Hz	1.38kW 4.8A	60Hz	1.48kW 5.1A	60Hz	2.83kW 8.9A	60HZ	3.43kW 10.2A	60Hz	5.40kW 15.7A
230V	50Hz	0.82kW 2.9A	230V 50Hz	1.39kW 4.6A	230V 50Hz	1.46kW 4.9A	230V 50Hz	2.92kW 8.6A	230V 50Hz	3.41kW 9.9A	230V 50Hz	5.38kW 15.4A
2300	60Hz	0.83kW 2.8A	230V 60Hz	1.38kW 4.6A	230V 60Hz	1.48kW 4.7A	230V 60Hz	2.83kW 8.3A	60Hz	3.44kW 9.8A	60Hz	5.41kW 15.3A
380V		1.8A	380V	2.8A	380V	3.0A	380V	4.9A	380V	5.7A	380V	9.1A
400V		1.7A	400V	2.6A	400V	2.8A	400V	4.7A	400V	5.4A	400V	8.7A
415V	50/60Hz	0 93KW 1.6A	415V 50/60Hz	1.38kW 2.5A	415V 50/60Hz	1.48kW 2.7A	415V 50/60Hz	2.77kW 4.5A	415V 50/60Hz	3.43kW 5.2A	415V 50/60Hz	5.40kW 8.4A
440V	30/00112	1.5A	440V 30/00112	1.50KW 2.4A	440V 30/00112	1.46KW 2.6A	440V 50/00112	4.3A	440V 30/00112	4.9A	440V 30/00112	7.9A
460V		1.5A	460V	2.3A	460V	2.5A	460V	4.1A	460V	4.7A	460V	7.5A
480V		1.4A	480V	2.2A	480V	2.4A	480V	3.9A	480V	4.5A	480V	7.3A



AKJ569, AKJ909, AKJ1509


Oil cooling uni	t horsepov	er (HP)					2.0					3.0					5.0	
		AKJ569									AKJ909					AKJ1509		
Model name			Stand	dard	-В	-C	-H	Different voltage specifications ¹³	Standard	-В	-C	-H	Different voltage specifications*3	Standard	-В	-C	–H	Different voltage specifications*3
Cooling capac	ity (50/60 l	Hz)*1 kW	/				5.0/5.6					8.0/9.0					15.0/15.0	
Heater		kW	/		-		2	-		-		4	-		-		4	-
Supply power*	Main	circuit	Thr	Three-phase 200/200 • 2		20 VAC 50/60 Hz	*3	Three-p	ohase 20	00/200•	220 VAC 50/60 Hz	*3	Three-p	hase 20	00/200•	220 VAC 50/60 Hz	*3	
Power voltage		ating circuit							l			DC12/24 V						
		200V 50 Hz			2.7		9.4 A			3.3	B kW/1				5.4	0 kW/1	73A	
	When	200V 60 Hz	-			72 kW/9		*8			3 kW/1		*8			7 kW/1		*8
Maximum power consumption/	cooling	220V 60 Hz	_			33 kW/8					3 kW/1					0 kW/1		
maximum current		200V 50 H	_		_	, , , , ,	2.32 kW/7.1 A	_		_	,	4.42 kW/13.1 A	_		_	O 1, 1	4.60 kW/13.8 A	_
consumption	When	200V 60 Hz	-		_		2.33 kW/7.1 A	_		_		4.45 kW/13.1 A	_		_		4.60 kW/13.7 A	_
	heating	220V 60 Hz	_		_		2.79 kW/7.8 A	_		_		5.33 kW/14.4 A	_		_		5.49 kW/14.9 A	_
Transformer ca	anacity						·	2.79 kVA				_	5.02 kVA					7.7 kVA
Exterior color	ариону							2.70 1071	<u> </u>			Ivory white	0.02 1(1)(7.7 1077
External dimer	neione (H v	W × D) mm	+			1.4	40 × 470 × 500		l		1 61	× 560 × 620				1 0	60 × 735 × 725	
	,		_				valent to 1.5 kW					alent to 2.2 kW		For	uivalar		kW + equivaler	at to 0 0 14M
Compressor (F Evaporator	lermenc D	5 Swillig type	"			Equi	valent to 1.5 kvv		<u> </u>					Eq	uivaiei	11 10 1.0	KW + equivale	IL IO 2.2 KVV
												pen coil type						
Condenser	Matan							400	2.14/		Cit	oss-fin coil type					10014/0	
Propeller fan	Motor							100	D W			1 10 00 11	40				100 W×2	
Agitator	Motor		_	Three phase AC, 60 W, 4P Room temperature or machine temperature* (Set to "Room temperature: Mode 3" by default)														
izafo	Standa		-				Hoom tem	perature or m	nacnine	tempe		,		Mode 3	s" by a	etauit)		
Temperature adjust	Object to	be controlled ronization										fluid temperature						
(Selectable)								–9.9 to +9.	.9 again	st the s		rd temperature (default)				
` / p	Φ	be controlled	_					Tank fluid temperature										
		°C	;									5 to 50						
Oil temperature		r resolution							±0.1°C									
Capacity contr												0 to 100%						
Timer function							ON timer: 1 to 999 hours (1-hour unit setting)											
Refrigerant cor								Compressor revolutions by inverter + Opening of electric expansion valve										
Refrigerant (R41	10A) *⁵ Fillin	g amount ko	1				1.07					1.58					2.65	
Protection devi	ices/protec	tive function	s		restart prot	preven ection t	tion timer, low re thermostat, refri	oom tempera gerant leakag	ture pro	otection ctor set	thern	stat, condenser nostat, high fluid it breaker (–B typ tion temperature	temperature e only), high	protecti -pressu	ion the	rmosta ssure s	t, low fluid temp witch (–C type o	erature nly),
	oom tempe	rature °C	;									5 to 45						
Operating Ta	nk fluid ter	nperature°C	; [5 to 50						
	I viscosity	mm²/s	6									0.5 to 200						
Acceptable flui	id						Water-soluble					nding oil, lubricat ugs, food produc		ulic oil,	indust	rial wat	ter	
Operating sour measurement i (Front 1 m, hei	n an anech						65					68					69	
	ransport vibration performance						Up a	and down vib	ration 1	14.7 m/	s² (1.5	G) × 2.5 hr (7.5 t	o 100 Hz sw	eep/five	min.)			
Protective stru	rotective structure*6											IP2X						
Mass		kç	,		72		75	97		89		93	117		140		144	180
(Rated current)	folded-case circuit breaker Rated current) A			-	15		-		-	20		-		-	30			
Items Ci	lolded-cas ircuit break Rated curre	er ent) A	15	(Re	quired	for typ	es other than th	e -B type)*7	20 (Re	equired	for ty	oes other than th	e -B type)*7	30 (R	equire	d for ty	pes other than th	ne -B type)*7
prepared by the customer	evice other	than							Tank.	supply	numn	, float switch, retu	ırn filter					

Refer to Page 5 for explanatory notes.

Operating range

Note: 1. The mark © shows the standard point.


2. Be sure to use the unit within the range of use specified in (Use outside this range may cause unit failure.)









AKJ189



AKJ359




AKJ459









AKJ569



AKJ909



AKJ1509



- 1. The O symbol indicates the standard point. (Room temperature: 35° C/ tank fluid temperature: 35° C/ Fluid used : Water for AKJ 1509 / Oil; ISO VG 32 for others)
- 2. The cooling capacity varies depending on conditions including the room temperature, tank fluid temperature and the kinematic viscosity of the oil, etc.

OILCOOLING UNIT | 8




External Dimension Diagram

Note: Refer to Page 5 for more details.


• For the machining dimensions of the holes for installation on the tank, refer to page 12.

The positions of the bolt holes used for installing the product on the tank top plate are compatible with the AKZJ8 series, but the positions of the power supply/signal cable inlet ports are not.



Min (50)











External Dimension Diagram

Note: Refer to Page 5 for more details.

• For the machining dimensions of the holes for installation on the tank, refer to page 12.

The positions of the bolt holes used for installing the product on the tank top plate are compatible with the AKZJ8 series, but the positions of the power supply/signal cable inlet ports are not.









Notes for manufacturing of tank

- 1. Separate the fluid tank into at least three sections. Use the over-flow system and take measures so that foreign matter such as cutting chips and debris does not get into the suction line directly.
- 2. Arrange and locate the partition plates and piping position properly so that high-temperature fluid returned from the main machine and low-temperature fluid cooled by the Oil Cooling Unit are evenly mixed.
- 3. Design the tank so that the tank inside can be cleaned with ease (For instance, the tank upper plate can be removed).
- 4. Tank material: Stainless steel is recommended, but compatibility with the cooling fluid should be adequately considered. (Some grinding fluid tanks are made of general structural steel with the interior coated with epoxy resin.)



• Separate type When the depth of the tank is the "H" dimension in the figure above or less



- Note 1. If it is expected that cutting chips and debris will get into the tank, install efficient filters in the supply or return line.
- Note 2. If foreign matter such as cutting chips and debris deposit on and adhere to the cooling coil surface, the cooling capacity is deteriorated and this may result in failure.

OILCOOLING UNIT 12



AKC | Circulating type | SERIES | RoHS-compliant

OIL COOLING UNIT


Overview / Features

Inline type cooling unit for coolant

The inline type unit can be installed with only piping regardless of the depth of the coolant tank.

This unit also can be used for retrofitting in an existing tank.

Optional models with a built-in pump are also available.



Highly accurate temperature control model by inverter control

The coolant temperature can be controlled within ± 0.1 °C over the entire cooling load range (from 0 to 100% load) and this helps to increase the accuracy of machine tools.

Excellent energy savings

A Daikin original high efficiency IPM motor is adopted on the compressor. High energy savings are realized with inverter control technology built up through our air conditioning experience and R410A refrigerant that has high COP characteristics.

(Approx. 30% energy savings compared to the 8 Series)

Complies with RoHS Directives such as Lead-Free (Environmentally friendly unit)

The environmental load has been reduced in conformance with the RoHS Directive by restricting hazardous substances to levels below the reference value, etc.

Easy maintenance

The evaporator coil design has been improved to give more durability against clogging. It is also easy to disassemble and clean the evaporator coil.


Greater durability against oil mist and dust

Ingress protection range for the control box is improved, including upgrade to IP54 and adoption of sulfur-free parts.

Simple monitoring of operating status


Alarm information, operation time, etc., can be monitored from a personal computer.


- This is useful for speeding up the identification of parts that need maintenance according to the "Alarm information" readout and shortening machine down times.
- The "Operation time" is a guide to determining the replacement timing for consumables and maintenance intervals.
- * Monitoring from a personal computer requires a software tool (Hybrid-Win), the communications cable and the monitor harness.
- * Hybrid-Win and the instruction manual can be downloaded free of charge from our website (http://www.daikinpmc.com) after user registration.
- * The communications cable and the monitor harness must be purchased separately



System Configuration

Easy retrofit into the existing tank Evaporator improved for greater durability against clogging













1 Oil cooling unit identification code

AKC: High-accuracy inverter controlled oil cooling unit [Coolant circulating type]

Cooling capacity

35: Cooling capacity of 3.5 kW 56: Cooling capacity of 5.6 kW

3 Symbol of series (Symbol to represent model change)

Symbol of option type (C/H/200)/Non-standard number Options and their combinations

Option Symbol	Compliance with CE	With heater	Unit with pump
-C	✓	-	_
-H	-	✓	-
-200	-	-	✓
-CH	✓	✓	-
C200	✓	-	✓
H200	-	✓	✓
K200	✓	✓	✓

Special specifications (different voltages, with casters, etc.)

* * (3 numerical digits), C * * * (3 numerical digits), etc. Please consult us separately about special specifications.

Specifications

Oil cooling unit	horsepower	(HP)			1.2				2.0	
					AKC359				AKC569	
Model name			Standard	-C (CE compliant type)	-H (With heater)	-200 (With pump)	Standard	-C (CE compliant type)	-H (With heater)	-200 (With pump)
Cooling capacity (50/60 Hz)*1	kW		3.5/3.5	5	3.2/3.2		5.6/5.6	, , , , , , , , , , , , , , , , , , ,	5.3/5.3
Heater		kW		_	1	_		-	2	_
Supply power*2				-	Three-phase 200/20	0•220 VA	C 50/60 Hz			
Main circuit		Main circuit				Three-phase 200/20	0•220 VA	C 50/60 Hz		
Power voltage Operation circui							12/24 V	·		
		200 V 50 Hz		1.17 kW/4	.2 A	1.44 kW/5.3 A		1.78 kW/6.2	A	2.10 kW/7.4 A
Maximum power	When cooling	200 V 60 Hz		1.22 kW/4	.3 A	1.60 kW/5.5 A		1.87 kW/6.3	A	2.30 kW/7.6 A
consumption	cooming	220 V 60 Hz		1.21 kW/4	.1 A	1.60 kW/5.2 A		1.86 kW/6.1	A	2.30 kW/7.3 A
Maximum current		200 V 50 Hz		-	1.19 kW/3.5 A	_		-	2.34 kW/7.0 A	_
consumption	When	200 V 60 Hz		-	1.19 kW/3.5 A	-		-	2.34 kW/7.0 A	_
	heating	220 V 60 Hz		-	1.43 kW/3.9 A	-		-	2.81 kW/7.6 A	_
Exterior color						lvory	white			
External dimension	ns (H × W × [D) mm		99	5 × 450 × 560	·		1,2	200 × 470 × 670	
Compressor (Hern				Equi	valent to 0.75 kW			Equ	uivalent to 1.5 kW	
Evaporator		•		·		Shell-end	coil type	·		
Condenser						Cross-fin	-coil type			
Propeller fan	Motor				54 W				100 W	
	Motor			-		0.4 kW-2P		-		0.4 kW-2P
Pump	Total head (st	tandard point, 50/60 Hz)		-		10/15 m		-		10/15 m
	Suction li	ft		-		0.5 m*3		-		0.5 m*3
tion	Standard			Room te	mperature or mach	ine temperature *4 (Set to "Ro	oom temperature: M	ode 3" by default)	
Temperature Light Temperature	Object to	be controlled		Fluid ir	nlet temperature or	fluid outlet tempera	ature (Set	to fluid inlet tempera	ature by default)	
control 5	§ Synchron	nization range K			-9.9 to 9.9 ag	ainst the reference t	temperatu	re (Set at 0.0 by def	ault)	
(Selectable)	_Φ Object to	be controlled			Fluid	inlet temperature o	or fluid out	tlet temperature		
(Selectable)	Object to Range	°C				5 to	50			
Fluid temperature	controller reso	olution				±0	.1°C			
Capacity control ra	ange					0 to	100%			
Timer function					10	l timer: 1 to 999 hou	ırs (1-hou	r unit setting)		
Refrigerant contro	I				Compressor revo					
Refrigerant (R410A	A) *5 Filling am	nount kg			0.80				1.25	
Protection devices	s/protective fur	nctions	restart pre refrigerant	A set of overcurrent relay (for a pump motor), discharge pipe temperature thermostat, condenser temperature thermostat, reverse-phase prestart prevention timer, low room temperature protection thermostat, high fluid temperature protection thermostat, low fluid temperature prefrigerant leakage detector, evaporator clogging detection (intake pipe temperature thermostat), invertoction device, circuit breaker (H type only), overheat prevention temperature switch (H type only), high pressure switch (C type only), and compressor thermal protect						
	Room tempe						45			
	Fluid inlet te	•					o 50			
Operation range	Fluid viscosi	<u> </u>			2	00 maximum (water		o ISO VG32)		
Operation range	Withstanding	•).2			
	Rated circulati	-					35			
	Circulating v	olume L/min					nimum			
Usable fluids *6						pass through filter e	equipment	ible) coolant, (grindi t with a 40-mesh or f		
	Fluid inle						3/4			
	Fluid outl						3/4			
Connecting tube Fluid drain port						Rc1				
	Priming p						1/2			
	Oil pan d			-		Rc3/8		-		Rc1/2
Noise level *8 (Value me value equivalent as mea	asured in anechoic				62				65	
Permissible transp					Up and down vi		,	5 to 100 Hz sweep/5	5 min.)	
Ingress protection	*9						2X			
Mass		kg		83	86	105		100	106	122
Molded-case circu		,			10				15	
Items prepared by	the customer			Circulating	pump	_		Circulating	pump	-

The cooling capacity indicates the value at the standard point (fluid inlet temperature: 35°C, room temperature: 35°C, fluid used: ISO VG32, flow rate: rated circulating volume). This unit has about ±5% of product tolerance.

Use a commercial power supply for the power source. The use of an inverter power supply may cause burn damage to the unit. The voltage fluctuation range should be within $\pm 10\%$. If it is more than $\pm 10\%$, please consult us.

Indicates the maximum value with clean fresh water.

The optional thermistor for machine temperature synchronization is required.

The SDS (Safety Data Sheet) of refrigerant R410A is attached to the –C type.

The SDS (Safety Data Sheet) of reingleant N4 IDA is attactive to the —t type. If the unit is used for a grinding machine or similar equipment, the evaporator tends to become clogged with foreign material, necessitating frequent maintenance of the evaporator or leading to significantly shorter pump service life due to wear of the pump parts (mainly the mechanical seals). This unit is cannot be used for water, chemicals, foods or fuels. Not applicable to models without a pump
The rotational speed of the fan varies depending on the room temperature to conserve energy. Therefore, it is normal for its operating sound to vary accordingly.


Ingress protection for switch box: equivalent to IP54 (When wired with IP54 or higher conduit tube or other protection on the wiring port.)

OILCOOLING UNIT 14






AKC359



- 1. The O symbols indicate standard points. (Room temperature: 35°C, inlet fluid temperature: 35°C, flow rate: 35 L/min., fluid used: ISO VG32)
- 2. The cooling capacity varies depending on the room temperature, fluid temperature, the kinematic viscosity of the fluid, etc.


AKC569



- $1.\ The\ O\ symbols\ indicate\ standard\ points.\ (Room\ temperature:\ 35^{\circ}C,\ inlet\ fluid\ temperature:\ 35^{\circ}C,\ flow\ rate:\ 35\ L/min.,\ fluid\ used:\ ISO\ VG32)$
- 2. The cooling capacity varies depending on the room temperature, fluid temperature, the kinematic viscosity of the fluid, etc.

Internal Pressure Loss


For the selection of the oil pump size and piping system, such as diameter and length of pipes, refer to the chart below. Pay attention to making the oil flow rate 15 L/min or greater.



Flow Rate Characteristics for Models With a Pump


(Internal pressure loss included)

The chart below shows the flow rate characteristics of the pumps with the internal pressure loss taken into account. Select the diameters and lengths of pipes by referring to the chart below so that a circulating volume of 15 L/min or greater can be maintained.






AKC359 (-C) (-H) (-200)




Part No.	Name	Description			
1	Fluid inlet	Rc3/4			
2	Fluid outlet	Rc3/4			
3	Fluid drain port	Rc1 Plugged			
4	PRIMING*	Rc1/2 Plugged			
5	Control panel				
6	Electrical component box lid				
7	Power supply inlet (Right / Left)	φ28 Hole			
8	Signal line inlet (Right / Left)	φ22 Hole			
9	Eye plate	φ25 Hole			
10	Air filter				


*Models other than those with a pump cannot
be used

n	Part No.	Name	Description
	11	Room temperature thermistor	
	12	Machine nameplate	
1	13	Design nameplate	
ed	14	Instruction nameplate	
	15	Overall caution plate	
	16	Electric schematic diagram nameplate	
	17	Battery charge mark nameplate	
	18	Cutting injury caution nameplate	
	19	High temperature caution nameplate	
	20	Model name nameplate	
ot	21	Oil pan drain*	Rc3/8 with PLUG Models with a






AKC569 (-C) (-H) (-200)




No.	Name	Description
1	Fluid inlet	Rc3/4
2	Fluid outlet	Rc3/4
3	Fluid drain port	Rc1 Plugged
4	PRIMING*	Rc1/2 with PLUG
5	Control panel	
6	Electrical component box lid	
7	Power supply inlet (Right / Left)	φ28 Hole
8	Signal line inlet (Right / Left)	φ22 Hole
9	Eye plate	φ25 Hole
10	Air filter	

*Models other than those with a pump cannot be used.

	Part No.	Name	Description
	11	Room temperature thermistor	
	12	Machine nameplate	
	13	Design nameplate	
JG	14	Instruction nameplate	
	15	Overall caution plate	
П	16	Electric schematic diagram nameplate	
	17	Battery charge mark nameplate	
	18	Cutting injury caution nameplate	
	19	High temperature caution nameplate	
	20	Model name nameplate	
t	21	Oil pan drain*	Rc1/2 with PLUG Models with a





OILCOOLING UNIT 16

Thermistor (Compatible with all types of Oil Cooling Unit 9 series)


■ Thermistor models and applications

When this optional part is installed in the main machine or oil piping, the thermistor detects the temperature to allow the control of oil temperature.

Name	Model	Length of lead wire L (m)	Figure	Application (To be installed by you)	Applicable model
	AKZ 9-OP-K5	5 m	Plug-in terminal	For machine	
onization	AKZ 9-OP-K10	10 m	27.5 Lead wire : 5	temperature synchronization control (implanted in the main machine)	
e body synchr	AKZ 9-OP-K15	15 m			AKJ9 Series, AKC9 Series
Thermistor for machine body synchronization	AKZ 9-OP-A5	5 m	Plug-in terminal L 80	For machine temperature synchronization	ANC9 Series
È	AKZ 9-OP-A10	10 m	Lead wire	control (attached to the surface of the main machine)	


Thermistor characteristics: Resistance value ... R25 (Resistance value at 25°C) = 20 k Ω , Tolerance: $\pm 3\%$

Instruction for installation and connection





■ Installation positions of the thermistors for machine temperature synchronization.



Extension board for main machine communication


The following functions are enabled by mounting this option board on the Oil Cooling Unit and connecting it to the main machine:

- 1. The operation mode and the operation setting can be changed from the main machine.
- 2. The alarm code and temperature data (machine temperature, room temperature, tank fluid temperature, inverter frequency) of the Oil Cooling Unit can be read from the main machine.

Communication method	Model	Installation position	Applicable model	Specification sheet No.
Serial communication only	AKZ9-OP-CS	Installation plate inside control box	AKJ189, AKJ359, AKJ459, AKJ569, AKJ909, AKJ1509, AKC359, AKC569	PSP04664

Note: 1. Refer to the specification sheet for the communication procedure and specifications.

■ Installation position for AKZ9-OP-CS (serial communication only)




- \bullet Dimensions of communication board (W \times H): 40×50
- \bullet The communication board is secured at four positions by locking support.

AKJ9 / AKC9 SERIES



Part Names, Functions and Operation of Control Panel





NO.	Item	Description					
1	Power lamp (Green)	The lamp is continuously on while power is supplied.					
2	Error warning lamp (Red)	When an error occurs Level 1 alarm: The lamp keeps blinking. Level 2 alarm: The lamp is turned on					
3	Warning lamp (Green)	When a warning occurs Level 1 warning: The lamp keeps blinking. Level 2 warning: The lamp is turned on.					
4	Timer mode lamp (Red)	The lamp keeps blinking while the machine is at a stop in the timer mode.					
(5)	Operation mode display	Displays the mode of the control panel. NORMAL: Normal mode MONITOR: Monitor mode SETTING: Operation setting mode TIMER: Timer setting mode					
6	Operation mode / Data No. display	Displays the current operation mode (normal mode /operation setting mode) or data number of the data currently displayed on the data display.					
7	Data display	Displays various data. The data displayed differs depending on the operation mode and data number.					
8	[SELECT] Select key	Selects the operation mode.					
9	[DOWN] key	Decrements the value of the operation mode, data number or data by 1. When held for two seconds or longer, decrements the values by 10.					
10	[UP] key	Increments the value of the operation mode, data number or data by 1. When held for two seconds or longer, increments the values by 10.					
11)	[ENT] (Confirm) key	Determines the operation mode, data number, and data to be changed.					

■ Operation for change to each mode

A mode can be changed by operating the \bigcirc key in general.

To enter a special mode, hold down a number of keys in combination for more than five seconds.







Operation Mode and Setting Method

AKJ9 Series

Operation Mode No.	Mode name	Mode name Description S		Necessary optional part
0	Tank fluid temperature, fixed temperature control	Maintains the tank fluid at a fixed temperature	5 to 50°C	
3	Tank fluid temperature, room temperature synchronization control	Synchronizes the tank fluid temperature with the room temperature	Room temperature -9.9 to +9.9 (K)	
4	Tank fluid temperature / machine temperature synchronization control	Synchronizes the tank fluid temperature with the machine temperature	Machine temperature -9.9 to +9.9 (K)	Machine synchronization thermistor

AKC9 Series

Operation Mode No.	Mode name	Description	Setting temperature range	Necessary optional part
0	Inlet fluid temperature, fixed temperature control	Maintains the inlet fluid at a fixed temperature	5 to 50°C	
1	Outlet fluid temperature, fixed temperature control	Maintains the outlet fluid at a fixed temperature	5 to 50°C	
3	Inlet fluid temperature, room temperature synchronization control	Synchronizes the inlet fluid temperature with the room temperature	Room temperature -9.9 to +9.9 (K)	
4	Inlet fluid temperature / machine temperature synchronization control	Synchronizes the inlet fluid temperature with the machine temperature	Machine temperature -9.9 to +9.9 (K)	Machine synchronization thermistor
5	Output fluid temperature / room temperature synchronization control	Synchronizes the outlet fluid temperature with the room temperature	Room temperature -9.9 to +9.9 (K)	
6	Outlet fluid temperature / machine temperature synchronization control	Synchronizes the outlet fluid temperature with the machine temperature	Machine temperature -9.9 to +9.9 (K)	Machine synchronization thermistor


Note: Refer to Page 17 for details of required optional parts.

■ Setting procedure

Default setting: Set to operation mode 3, and a temperature of "0.0" °C

When you use your machine at a setting other than the default setting, change the setting following the procedure shown below.

- 1 Power ON Release the operation lock mode before starting operation for the first time. (Hold down the ☑ and ☒ keys together for at least 5 seconds.)
- 2 Select the "SETTING" operation setting mode (press the key once).



Return to the "NORMAL" mode by pressing the key three times.

Checking Data in the Monitor Mode

The following data can be checked in the monitor mode.

Monitor No.	Description						
WOTHER INC.	AKJ9	AKC9	Note				
0	Machine body temperature [Th1]						
1	Outlet fluid temperature [Th2]						
2	Room temperature [Th3]						
3	Tank fluid temperature [Th4]	Inlet fluid temperature [Th4]	*1				
4	Intake gas temperature [Th5]		*1				

Monitor No.	Description						
WOTILOT INO.	AKJ9	AKC9	Note				
5	-	ΔT [Th4 - Th2]	*1				
6	Cooling capacity control command value (%)						
7	Compressor inverter rotational speed (rps)						
8	Power consumption (kW)						
9	Extended DIN (hundreds digit), DOUT (tens digit) status						

^{*1.} If the thermistor is not connected or has a broken wire, -99.9 is displayed.


OILCOOLING UNIT | 20



^{*2.} With the default setting, 0 is displayed. Note that display is enabled when parameter n020 is "1" or the optional communication extension board is installed.

^{*3.} This is the roughly calculated value with a power supply voltage of 200 V (the error is approximately 20%).


Electric Schematic Diagram (Representative Model of AKJ9 Series)







Electric Schematic Diagram (Representative Model of AKC9 Series)



OILCOOLING UNIT | 22



Electric Wiring Connection Instruction Diagram

1 Power supply capacity ... Power supply capacity ... Refer to the maximum power consumption/maximum current consumption panel of the specifications list (Pages 5, 6 and 14).

2 Connection to power supply terminal block (X1M, Tr)

- (1) AKJ**9: With the standard and optional (-C, -H, -046) types:
 - Connect to X1M.
- (2) AKJ**9: With the "with breaker" (-B) specifications:

AKC**9: All models:


- Connect to the breaker.
- (3) AKJ**9: With different voltage types (with transformer: -047, -048):
 - Connect to the terminal block supplied with the transformer.

1. Screw terminal and wiring diameter

	Terminal	Screw	Wiring diameter			
Series	block	terminal	JIS cable	IEC cable	UL cable	
AKJ 189, 359, 459, 569	X1M	M4	2.0 mm ²	2.5 mm ²	AWG#14	
AKC 359, 569	Breaker	M5	or more	or more	or more	
AKJ 909.1509	X1M	M5	3.5 mm ²	4.0 mm ²	AWG#12	
AKJ 909, 1509	Breaker	M5	or more	or more	or more	

- 2. Use a round crimp-style terminal for connection.
- 3. The terminal block is for three poles and the ground wire is to be secured on the enclosure with a screw.


3 Connection to signal terminal block (X2M)




1. Straight crimp terminal and wiring diameter

Otraialitation to main als	Wiring diameter						
Straight pin terminals	JIS cable	IEC cable	UL cable				
*	0.25 mm ² to 1.25 mm ²	0.3 mm ² to 1.5 mm ²	AWG#22 to #16				

- 2. Use a straight crimp-style terminal for connection.
- 3. Use stranded wires for electric connection.
- 4. The wiring size is 0.5 mm2 to 1.5 mm2 in the case of duplex cable according to IEC. If using stripped wires, make the stripped length 9 to 10 mm.
- * Recommended models and manufacturers: TGN TC-1.25-9T (NICHIFU Co., Ltd.) APA-1.25N (Daido Solderless Terminal)







DANGER

- 1. Always install an all-pole (3-pole) circuit breaker* (to be prepared by the customer) of the specified capacity on the main power supply.
 - All contact distances must be at least 3 mm.
- 2. Always ground the machine. Since a noise filter is installed, there is a risk of electrical shock without proper grounding.
- 3. Before opening the electric component box, always turn off the power, and wait for 5 minutes until internal high voltage has been discharged.
- 4. Do not energize the equipment with the electric component box kept



CAUTION

- 1. To avoid the effects of noise, connect the power wire by cutting it to the proper length so that no excess wire comes into contact with the control board or others.
- 2. To perform remote control, remove the short-circuit wire between [10] and [11] and install an operation switch (to be prepared by the customer).
- 3. The mode is set to "Lock mode (Stop mode)" by default. Before starting operation, follow the procedure to release the Lock mode from the operation panel. Refer to the operation manual for the unlocking procedure.
- 4. The unit is provided with a misoperation prevention switch (PROTECT) to reject setting from the operation panel. If you want to use this function, make the necessary setting referring to the operation manual.

4 Signal output time chart

(1) Alarm/operation status output chart

	Oper	ation status		Remote operation (be				petween [10] and [11])			
				ON				0	FF		
Signal output			Normal	Level 1 error or Lock	Level 2 error	Power failure (Power OFF)	Normal	Level 1 error or Lock	Level 2 error	Power failure (Power OFF)	
Normal ("a" contact)	60 - 61	ON OFF									
Error / Stop (Power OFF) ("b" contact)	60 - 63	ON OFF									
Error level ("a" contact)	60 - 64	ON OFF									
Agitator operation (NO contact)	61 - 62	ON OFF									

(2) Warning output chart

	Оре	ration status	Non-warning status				Warning status			
Signal output			Normal	Level 1 error or Lock	Level 2 error	Power failure (Power OFF)	Normal	Level 1 error or Lock	Level 2 error	Power failure (Power OFF)
Warning output (NO contact)	66 - 67	ON OFF								



- CAUTION 1. The following electric wires can be used on the terminal block for straight crimp-style terminals.
 - Single wire: $\phi 0.57$ to $\phi 1.44$ (AWG#22 \sim #16) Stranded wire: 0.25 mm² to 1.25 mm² (AWG#22~16)
 - 2. Load applicable to [60 64] and [66 67] is as follows: Min. applicable load: 10mV DC, 10 μA or more

Max. applicable load: 30 V DC, 2 A (Resistance load)

- 3. For [10] to [13], please prepare contacts to meet the condition of minimum applicable load 12 V DC and 5 mA.
- 4. When the length of the thermistor to be connected to [30] - [31] is longer than 10m, or the wiring is routed in a poor noise environment, use shielded wire.



Notes for Handling

• Important notes to be observed regarding the main machine side (machine tools and industrial machinery)

- 1. When rough transport conditions are expected while transporting the machine overseas or elsewhere, special precautions should be taken in the packaging and transportation method so as to avoid the application of excessive force on the oil cooling unit (this unit).
- 2. Oil Cooling Unit (this machine) does not incorporate a flow switch for checking the oil supply and a temperature switch for abnormal supply of oil temperature (high temperature or low temperature). So, please provide a protection device such as a flow.

Notes for operation and cooling capacity

- 1. Do not use the oil cooling unit to cool a fluid from 50°C or higher. Start to operate the oil cooling unit at the same time as the main machine or before the fluid temperature rises to 40°C.
- 2. Do not place an object that hinders ventilation within 500 mm of the air-intake or exhaust.
- 3. If the air filter is clogged, the cooling capacity is reduced. Clean the air filter (wash with hot water or clean with air) periodically once every two weeks to prevent clogging.
- 4. If cutting chips and powder-like chips deposit on and adhere to the cooling coil (evaporator) in the AKJ9 series, the cooling capacity should be diminished and it could cause failure. To avoid the adherence of deposits on the cooling coil, install an efficient return filter on the return side (fluid inlet) of the tank and periodically clean the tank inside.

Notes regarding fluid usable with Oil Cooling Unit

- 1. The fluid usable with the oil cooling unit is listed in the table below for each series. (symbol ... Can be used, "Unusable" symbol ... Cannot be used)
- 2. Do not use fluid listed below as "unusable"

	Description	AKJ 9 Series	AKC 9 Series
Lubrication oil Mineral hydraulic oil	Oil that is classified as third class petroleum or fourth class petroleum of the fourth group hazardous materials stipulated in the Fire Defense Law and that corresponds to discoloration No. 1 in the copper corrosion test method (JIS K2513) of petroleum products	✓	√
Nonflammable hydraulic oil Phosphate ester hydraulic fluid Chlorinated hydrocarbon series Water - Glycol series W/O - O/W emulsion series (High-aqueous hydraulic oil)		Unusable	Unusable
Coolant fluid Water-soluble cutting and grinding fluid Non water-soluble cutting and grinding oil		√	✓
Ethylene glycol (Antifreeze liquid)	Fluid not including any ingredient that corrodes the SUS304 material used for the	✓	Unusable
Water (Industrial water)	evaporator coil	✓	Unusable
Inflammable liquid like fuel	Liquid equivalent to special flammables, alcohol, first class petroleum and second class petroleum of the fourth group hazardous materials specified according to the Fire Defense Law	Unusable	Unusable
Drugs		Unusable	Unusable
Liquid for food products	Drinking water, water for cooling food products, etc.	Unusable	Unusable

AKJ9 / AKC9 SERIES

lectric Wiring Connection Instruction Diagram /

OILCOOLING UNIT 24



Complementary Information

Notes for Handling

* Before operating the product, be sure to read and understand the operation manual supplied with it.

• Instructions for safe operation

(Signs and Instructions)

MARNING Failure to observe the instruction may result in death or serious injury.

ACAUTION Failure to observe the instruction may result in personal injury or damage to property.

1 General instructions

[ANGER] ① Use the product only in accordance with the intended specifications (specified in brochure, specification sheet, operation manual, and caution plates).

[ANGER] 3 Do not disassemble, repair or modify the equipment by yourself.

[Always comply with the laws and regulations for safety (Industrial Safety and Health Law, Fire Defense Law, and JIS B 8361 Guidelines of Hydraulic System).

[NARNING] 5 Caution in the event of refrigerant leak

- Ventilate the room adequately (to avoid the risk of suffocation).
- · Avoid direct contact of the refrigerant with skin (to avoid the risk of cryogenic burns).
- In the event of inhalation of a great deal of refrigerant, contact with skin, or refrigerant in the eye, seek medical attention immediately.
- [A WARNING] (6) In the event of an abnormal condition, stop operation promptly, investigate the cause of the problem and take appropriate remedial measures.
- ② Do not use the unit in atypical environments (locations subject to high temperatures, high humidity, or a lot of dust, contamination, steam, oil mist or corrosive gases: H2S, SO2, NO2 or Cℓ2).
- [A CAUTION]

 (8) Install a flow switch and temperature switch on the main machine to protect the main shaft and others.
- [ACAUTION] 9 Do not get on the equipment or place an object on the equipment.

2 Instructions for transportation

- ① When hoisting the equipment, check its weight and use the eye plates and hangers on the equipment properly.
- [NARNING] ② Do not get approach the equipment while it is being hoisted and moved.
- [AUTION] 3 When moving the equipment, take appropriate measures for fall prevention.
- [AUTION] Do not tilt the equipment 30 degrees or more while transporting the equipment (including during storage).

(3) Instructions for installation

- [AUTION] ② Do not place an object near the suction port and discharge port of the equipment.

(4) Instructions for wiring and piping installation

- [\(\DANGER \)] Wiring and piping installation should be performed by a person with specialized knowledge and skills.
- [Always use a commercial power supply for the power source. (The use of an inverter power supply may cause burn damage).
- [A DANGER] 3 Connect the wiring for power supply in accordance with the electric wiring instruction diagram of the specification sheet and operation manual.
- [! DANGER] 4 Ground the equipment properly.
- [1 WARNING] (5) Install the wiring in accordance with the standard by checking the electric schematic diagram.
- [AUTION] (a) Always install a dedicated breaker (all-pole (3-pole) molded case circuit breaker) appropriate for the capacity of the Oil Cooling Unit on the main power supply on site.
- [AUTION] ① Check that piping for coolant has a pressure resistance of at least 1 MPa and make proper connections. (For AKC)

5 Instructions for trial run

- [AUTION] ① Check to see that the main machine is in a safe status (not activated) before starting the trial run.
- [AUTION] ② Check to see that the fluid piping and electric wiring are correctly connected to the main machine and that there is no looseness in connections and joints.
- [ACAUTION] ③ Disable the operation lock of the equipment (Oil Cooling Unit) before starting the main machine.
- [A CAUTION] 4 Check that the tank contains the correct volume of the fluid used. (For AKJ)

(6) Instructions during operation

- [A DANGER] ① Do not splash water or fluid on the equipment.
- [WARNING] ② Do not push your finger or an object into gaps of the equipment.
- [AUTION] 3 Do not touch the heated exhaust port of the equipment.

(7) Instructions for maintenance and inspection

- [DANGER] ① Perform maintenance and inspection with the equipment kept open. Working in a closed status may result in suffocation due to the leak of refrigerant.
- [Always turn off the main power supply before starting maintenance and inspection.
- [ADANGER] 3 Wait for five minutes after turning off the main power supply and start maintenance and inspection operation.
- ⚠ DANGER] ④ Do not operate the equipment with the cover of the equipment opened.
- [\triangle CAUTION] **(6)** Clean the air filter periodically (once every two weeks in general).
- [AUTION] ① Clean the cooling coil periodically to ensure that there is no accumulation/adhesion of chips, etc. (For AKJ)



In the case of cooling of cutting and grinding fluid

- 1. The amount of heat generation from the cutting and grinding fluid system should be roughly estimated according to the following formula as the tank capacity and pump flow rate are generally large. After rough estimation, the amount of heat generation should be determined by conducting tests on the actual machine to select the oil cooling unit.
- 2. Formula for rough calculation of amount of heat generation

Q = Q1 + Q2 + Q3

Q : Heat load of the entire machine tool system

Q1: Amount of heat generated during machining on a machine tool

Q2 : Amount of heat generation of the pump motor for coolant pump (Amount of heat transferred to coolant)

: Q2 = pump motor output (kW) $\times \frac{\eta}{100}$


Q3: Heat balance of the coolant fluid passing through the coolant tank and the room temperature

K : Rate of heat passage (W/m² \cdot °C), generally K = 11.6 to 23.2 A: Surface area of the tank in contact with the fluid (m2)

△T : Room temperature – controlled temperature of fluid in tank (°C)

3. For testing, determine the amount of heat generation according to the method shown below.

General guide for heat generation



E.g.) In the diagram above,

When
$$Q1 = 1.2 \text{ kW}$$


Q2 =
$$(2.2 + 2.2 + 3.7) \times \frac{50}{100} \approx 4.1$$
 kW (For a coolant pump, " η " is generally 50%.)

$$Q3 = 20 \times 4 \times (35 - 25) / 1000 = 0.8 \text{ kW}$$

$$\therefore Q = Q_1 + Q_2 + Q_3$$

$$= 6.1 \text{ kW}$$

Method:Estimating the amount of heat generation from the rate of increase of the fluid temperature in the tank



Find the maximum gradient of the fluid temperature rise.

To do this, it is necessary to measure $\triangle t$ every minute during the first 10 minutes.

$$Q = 2.778 \times 10^{-7} Cp \cdot \gamma \cdot V \cdot \triangle t/H$$

Q : Heat release value (kW)

Cp: Constant pressure specific heat (J/kg°C) · · · 1967.4 J/kg°C

: Weight volume ratio (kg/m³) · · · 876 kg/m³

: Total oil quantity (m3)

 $\triangle t$: Temperature difference (°C) ... t_1 - t_2

H: Time (h)

E.g.) When the total oil volume is 300 L (0.3 m³) and " \triangle t" is 10°C.

$$Q = 2.778 \times 10^{-7} \times 1967.4 \times 876 \times 0.3 \times 10$$

$$= 0.479 \times 0.3 \times 10 \approx 1.4 \text{ kW}$$

OILCOOLING UNIT | 26





DAIKIN INDUSTRIES, LTD.

Oil Hydraulic Division

Osaka Office

YODOGAWA PLANT 1-1, Nishi-Hitotsuya, Settsu, Osaka 566-8585, Japan Home Page: http://www.daikinpmc.com/en/

Overseas service network

Please contact Daikin Sales Counter for servicing of Oil Cooling Unit in countries outside Japan. Daikin is ready to offer you service in conjunction with the sales agents of our Air-conditioning and Hydraulic Divisions located in seven countries and regions worldwide.

Country/Region	Locations	Company name
China	Shanghai	◎ DAIKIN HYDRAULICS (SUZHOU) CO., LTD. 上海分公司(Shanghai Branch)
	Dalian	◎ DAIKIN HYDRAULICS (SUZHOU) CO., LTD. 大連分公司(Dalian Branch)
	Beijing	◎ DAIKIN HYDRAULICS (SUZHOU) CO., LTD. 北京営業所(Beijing Office)
	Guangzhou	◎ DAIKIN HYDRAULICS (SUZHOU) CO., LTD. 広州営業所(Guangzhou Office)
	Shenyang	◎ DAIKIN HYDRAULICS (SUZHOU) CO., LTD. 瀋陽営業所(Shenyang Office)
Korea	Seoul	⊚KD HYDRAULICS,LTD.
Taiwan	Taipei	HO TAI DEVELOPMENT CO.,LTD.
Singapore	Singapore	©ZICOM PRIVATE LTD.
Thailand	Bangkok	SIAM DAIKIN SALES CO., LTD.
India	New Delhi	DAIKIN AIR CONDITIONING INDIA PVT.LTD DELHI BRANCH
U.S.	Illinois	⊚ALL WORLD MACHINERY
Sales agents of h	(As of Oct. 30, 2015)	

OSales agents of hydraulic equipment.

Others are the sales agent of air conditioning equipment.

● Contents in this catalog are subject to change for improvement without prior notice.

GK248 (2015.12.020) DF.MD.MD

